



TOTAL SYSTEM: 3 x 340Wp PANASONIC VBHN340SJ53 PV MODULES (1590 x 1053 x 40mm); 1.02kWp

FOR APPROVAL



Scan our QR code to register your system on the C3 Hub for access to all your Operations & Maintenance information and to redeem your 10% service discount code!



Drawing N°			GO-ST001	
TITLE:				
Solar PV Layout				
Client:	T.B.C.			
Project:	Goodge Street			
Address:	9 Goodge Street., London, W1T 2PE			
SCALE	REV	DRAWN	CHKD	DATE
1:50	Α	MB	IR	11/02/2021



Solar PV System at: 9 Goodge Street, London, W1T 2PE

ROOF 1.02 kWp PV ARRAY TOTAL SYSTEM 1.02kWp 3 x PANASONIC VBHN340S53 **INVERTER RATED 0.75kW** 3 x PANASONIC VBHN340SJ53 ROOFTOP DC CABLE 4mm² DOUBLE-INSULATED CU PV-1F CONDUCTOR SINGLE-PHASE, PROTECTIVE & NEUTRAL INVERTER GROWATT 750-S CONDUCTOR SINGLE-PHASE & NEUTRAL INCLUDES **INVERTER** INTEGRATED DC **ISOLATOR** LOCATION CONDUCTOR, PROTECTIVE INV 1 1.5mm² 3C FLEX INVERTER LOCAL AC ISOLATOR 6A+ METER CUSTOMER'S DNO OPERATOR'S **EQUIPMENT** TN-C-S 1.5mm² T&E CU **EQUIPMENT** CONSUMER CUSTOMER'S LOAD (TOTAL CIRCUIT CIRCUITS LENGTH FROM UNIT LOCATION ORIGIN NOT TO EXCEED 115m) IMPORT METER SOLAR PV I MAIN 6A+ 2P KWH MAIN AC LOCKABLE CORES OF **ISOLATOR** 1.5mm² T&E CABLE CU 6A 1P GRID CUT-OUT 100A GENERATION 230V LANDLORD'S BOARD METER AC 1~ SINGLE-PHASE KWH 1.5mm² T&E CU CLASS II Scan our QR code to register NO EARTH your system on the C3 Hub for EARTH OF 1.5mm² T&E access to all your Operations & CABLE 0.75mm² CU Maintenance information and to FOR APPROVAL redeem your 10% service discount code! REV: 0 DATE:11/02/2021 Start-up sequence: Disconnection Sequence: ER G98 Inverter Settings: Installer: 1) Over Voltage 262.2V (1s) / 273.7V (0.5s) 1) Turn off the mains AC at the isolator(s) next to the



61 London Road, Maidstone ME16 8TX

+44 (0)1732 810 303 office@carbon3.co.uk www.carbon3.co.uk

- 1) Ensure that all isolators and breakers in the Distribution Board area for the Solar PV installation are "on"
- 2) Ensure that the DC isolator(s) next to or on the inverter(s) are set to "1"("on")
- 3) Turn on the local mains AC isolator(s) next to the inverter(s)
- 4) Assuming sufficient daylight for generation, the "ON" or "Operation" light or the display will indicate that the system is functioning correctly
- The inverter(s) will automatically and safely disconnect. 2) Turn off the DC isolator(s) next to or on the inverter(s) (set to "0")
- 3) Wait 5 minutes before removing cover

- 2) Under Voltage 184V (2.5s)
- 3) Over Frequency 51.5Hz (15 min) / 52Hz (0.5s)
- 4) Under Frequency 47.5Hz (20s) / 47Hz (0.5s) 5) Loss of Supply ROCOF 1.0Hz/sec (0.5s)
- 6) Reconnection Time 20sec minimum