

Remove existing window & frame. Clear struts & framing. Fix new softwood door frame French windows
(door to be half glazed)

Remove tiles & boards. Cut out rafters to re-arrange & fit to form flat roof. Nail down boards & cover with asphalt

plain tiles nailed on battens & sarking

cut existing asphalt and melt to form joint to new work

A ↑

New hand-rail screwed to joists located under existing roof (containing opaque glass)

asphalt skim laid to fall, pressed down into gutter

Form new vertical tile-hung surfaces using existing tiles

SLOPING TILED ROOF

Form new gutter

SLOPING TILED ROOF

5'-8" eop

WEST PILE

ASPHALTE ROOF

11'-1"

SLOPING TILED ROOF

A ↑

PLAN

1/4" = 1'-0"

CTP/G8/19/5/1112

LONDON BOROUGH OF CAMDEN

PLANS APPROVED

- 5 OCT 1971

ON BEHALF OF THE COUNCIL

CONVERSION TO ROOF
26B ETON AVENUE N.W.3
M. CURWEN ESQ.

SECTION A-A

Scale 1/2" = 1'-0"

2" x 2" struts at 14" cts.

5" x 2" rafters

Floor lvl

4" x 3"

9" x 3" trimmer.

6" x 3" main joists

5" x 2" joists