

Tree Work Schedule No. Species Works Categ T13 Callery Pear Fell to ground level and grind stump. All tree work is to be undertaken in accordance with British Standard BS 3998:2010 Tree work - Recommendations. All arising's are to be removed and the site is to be left as found. Care is to be taken of the ground around retained trees to make sure that it does not become compacted as a result of tree surgery operations. No equipment or vehicles such as timber lorries, tractors, excavators or cranes shall be parked or driven beneath the crowns of any retained trees, to prevent subsequent compaction and root death. Protective Fencing To be erected prior to the commencement of all works on site, and retained in place throughout construction. <u>Specification</u>: To comprise of 2m tall welded mesh panels on rubber or concrete feet. Panels are to be joined together using a minimum of two anti-tamper couplers, installed so that they can only be removed from installed the force. The same back and the sum of the inner side has inside the fence. The panels should be supported on the inner side by 0 stabilizer struts, which should should be attached to a base plate and secured with ground pins. All weather notices should be erected at regular intervals on the weld mesh panels with words such as "Construction exclusion zone - Keep Tree Protection Area **KEEP OUT** Do <u>not</u> move this fence (TOWN & COUNTRY PLANNING ACT 1990) (TOWN & COUNTRY PLANNING ACT 1990) REES ENCLOSED BY THIS FENCE ARE PROTECTED BY PLANNING CONDITIONS AND/OR ARE THE SUBJECT OF A TREE PRESERVATION ORDER. CONTRAVENTION OF A TREE PRESERVATION ORDER MAY LEAD TO CRIMINAL PROSECUTION ANY INCURSION INTO THE PROTECTED AREA MUST BE WITH THE WRITTEN PERMISSION OF THE LOCAL PLANNING AUTHORITY Arbtech Consulting Limited. Unit 3, Well House Barn, Chester Road, Chester, CH4 0DH https://arbtech.co.uk - 01244 661170 Construction exclusion zone A construction exclusion zone (CEZ) is a designated area where there is to be no construction activity what-so-ever. Access to the area for construction personnel or machinery is strictly prohibited and there is no scope for materials or waste storage etc. Arboricultural Supervision

supervise all demolition and construction works that have to be undertaken within the root protection areas. This will include: Pre-commencement site meeting. Location of protective measures.
Arboricultural sign off and removal of protective measures. Arboricultural Method Statement

A arbtech

Unit 3, Well House Barns, Chester, CH4 0DH https://arbtech.co.uk, 01244 661170

Cantelowes Gardens Camden Road London NW5 2AU

London Borough of Camden Tree Protection Plan Based on 2024 CAS 029 013 A Drawing No: Arbtech TPP 01 Scale: Drawn: Mar 2025 1:150 @ A0 FG Tree Canopies: Trunks: Category 'B' trees: Category 'C' trees: Trees to be removed: T13 Protective fencing: Category C' groups: