


PART SECTION

1. Install temporary piled foundations and pile caps
2. Install temporary steelwork beams and stub columns. Pre-deflect steel beams.
3. Needle thru or bolt to existing masonry columns to No. 10 & transfer column load to beams
4. Carry out remedial work to existing masonry column foundations such as forming a new pad at depth to suit new basement, or mini piling existing. Allow sufficient time for details to be agreed between PW Surveyors
5. Re-load new foundation by reversing above process



PART PLAN

Client
Mrs Abiola

Project
8 Pilgrim's Lane, NW3

Location

Location Plan

Drawing Title
Sketch of support to foundation No. 10

Project Number 612 **Drawing Number** SK 01 **Revision**

Date 08.07.13 **Scale** nts **Status** Planning

Drawn GL **Checked** - **Approved** -

Greig Ling
Consulting Engineers
50-52 Great Sutton Street
London EC1V 0DF
T 020 7689 5611
F 020 7689 5612
info@greiling.com
www.greiling.com

Greig-Ling

© Greig Ling Limited. All rights described in Chapter IV of the Copyright, Designs and Patents Act 1988 have been asserted. This drawing is to be read in conjunction with the specification and all relevant drawings. Contractor to check all dimensions on site. Do not scale from this drawing. Greig Ling Limited to be advised of any variation between the drawings and site conditions.