



New partitions to be built in timber stud. Joists spanning parallel to new partitions to be doubled up under studwork

Provide new timber lintels over new openings (assuming timber stud walls). Install 2No. 225x50 C24 timbers bolted together at 400c/c, using double sided toothed plate connectors

Use BAT Maxi Speedy joist hanger by Expamet, resin anchored into brickwork with 12mm diameter anchors

See SK02 (Roof) for rooflight trimming arrangement

Ellis & Moore LLP CONSULTING ENGINEERS 9 th Floor, Hill House, 17, Highgate Hill, London N19 5NA Telephone: 020 7281 4821	Project 20 AMPTON STREET	Date AUGUST 2012
	Title 3rd FLOOR	Scale NTS
		Drawing No. 13858-SK01