



TYPICAL SECTION

TYPICAL ELEVATION

REMOVE ALL OPENING GEAR. REMOVE ALL GLAZING. CLEAR OUT ALL BEDDING PUTTIES, RE-FIX GLAZING BEADS. FILL BETWEEN BEAD and FRAME WITH BITUMEN BASED MASTIC - DRILL and TAP FRAMES TO OPENING LIGHTS and SCEW FIX SHUT. INTAKE and EXTRACT LOUVRE TO BE FIXED TO HARDWOOD LINING/SURROUND FIXED TO INTERNAL REVEAL. NOTE:-LOUVRE TO BE POWDER COAT FINISH RAL 7001. SEE ALSO MECHANICAL SERVICES DETAILS.

READ THIS DRAWING IN CONJUNCTION WITH DRAWING No. 06600/12/PL05 FOR LOCATION OF WINDOWS AFFECTED BY THE LOUVRE INSTALLATION.





Tel: 01483 764407 email: mail @ bbf-flelding.co.uk

PROPOSED OPENREACH HQ 123 JUDD STREET LONDON, W1H 9NP

TYPICAL DETAIL AT WINDOW / LOUVRE INTAKE and EXTRACT

1:20 as drg. no.

06600/12/PL/07