



PLAN ON TW01 PROPS WHEN 2ND STAGE U/PINS TOWARDS NO 83/85 ARE COMPLETED

B.4 When all 2nd stage u/pins sufficiently cured, install TW01 and then remove TW-83

Typical back propping with acrow jacks as per TW-203

B.3 Install back props on completion of stem

B.2 Cast base and then stem. Dry pack joint under stage 1 u/pin or use letter box shutter to engineers specification.

B.1 Excavate 2nd stage u/pins in fully shored localised narrow shafts. individual pins are to be excavated in 1-4-2-5-3 hit and miss sequence.

Install TW01 and then remove TW-83

Sloping ground to safe angle of repose

AXIOM STRUCTURES LIMITED
 85 CAMDEN MEWS
 TEMPORARY WORKS PROPOSALS
 15005-TW-206 P1
 20.07.2015ap
 office@axiom-structures.co.uk
 m: 07738096317