

Stone staircase protection method

free before covering. All stone will be cleaned to ensure it is grit and dust

Felt – felt underlay applied to all risers

Sheeting - overlay fire resistant floor protection

tape over internal and external joints Plywood covering -18mm plywood and apply floor

protective taping to Plywood Stringer - cut in stringer in 18mm plywood, tread and riser joins

Stoneforce Ltd
Unit 2C Shakespeare Industrial Estate
Shakespeare Sitest, Watford
Herts. W1024 3RR
Tel: 108450 702 860
Eax: 08450 702 861
Eax: 08450 702 861

Contractor must verify all dimensions on site before commencing any work or shop drawings. If this drawing exceeds the quantities taken in any way the Architects are to be informed before the work is installed. Contractor must verify all dimensions on site before commencing any work or shop drawings. If this drawing exceeds the quantities taken in any way the Architects are to be informed before the work is installed.

Drawings based or Ordnance Survey and/or existing record drawings - design and drawing content subject to Site Survey, Structural Survey, Site Investigations, Planning and Statutory Requirements and Approvals.

Authorized reproduction from Ordnance Survey Map with permission of the Controller of Her Majesty's Stationery Office

				Rev	Revisions
				Description	
				Ву	
				Date	
Signature:	Date:			Signed off by:	
- NEW			21.0/.15	21 07 17	Date:
GT SF1862		!	_	1 117	Drawn By:
SF1862			N 13(8) A 3		Scale:
Plywood Stair Protection		Protection	Example Stair	T	Project: