



Connect all 3 transformers positive and negative 240 cables to your 240volt powder supply. using a connection box.

using 3no letters each for each transformer

The last letter in the line i.e “The the last led on the E - Y - N should be capped off.

so you need the 12volt positive and neg connections, gel connected to each of the positive and neg of the first led of each first letter (red is positive black is neg. on the transformers

The positive on the Leds is most likely the grey and the white the neg. but check with 12volt battery or other device.

then take the cable out (last led of each letter) of each first letter and gel connect together to the second letter on each set, then the second to the third testing each connection as you connect them.

testing at the end will cause problems if you don't know which connection is not working