



ACS Trees (Consulting) LEGEND

BS Root Protection Area, (RPA) shown uniform (above left) but site features such as roadways, retaining walls and foundations, may modify root patterns and therefore the RPA shape.



A grade trees



B grade trees



U grade trees



Trees to be removed



Recommended position for fixed tree protection fencing



Location of root investigations

Tree Protection Methods to be adopted on site.

1. Undertake pre-commencement site meeting to agree tree protection methods and timings.
2. Carry out any permitted tree works - ask before beginning.
3. Erect and fix in place all tree protection conform with BS 5837 (see Appendix 3).
4. Undertake demolition in accordance with contractor's specification
5. Clear debris from site.
6. Construction phase.
7. Remove tree protection.
8. Undertake landscaping.

Client: Adams Row
Project: 1 Norfolk Road
 London NW9
Title: Tree Protection Plan
Scale: 1:200 A3
Date: July 2015
Dwg No.: TFP2_NR_15
Rev: -

ACS Trees (Consulting)
 Consultants in Tree & Woodland Management
 Ripples Court
 15-17 West Street
 Reigate
 Surrey RH2 9BL
 T: 0208 687 1214 E: info@acstrees.co.uk W: acstrees.co.uk

