

EMOLITION KEY (SUFFIX DEM.)

01. REMOVE MODERN CABINETS

02 REMOVE MODERN KITCHEN EITTIN

. -

OF TEMOVE MODERAL DIRECTOR OF DE

07. REMOVE MODERN KITCHEN FITTI

ON DEMONE EXISTING ELOOD TIL

U9. REMOVE EXISTING FLOOR TIL

.. ______

12. REPLACE DOOR WITH NEW FULLY GLAZED DOOR. STRUCTURAL OPENNIN RETAINED

13. MAKE OPENNING TO CHIMNEY AND REISNTATE FIRE PLACE WITH SURROUND TO MATCH FIREPLACE AT GROUND FLOOR LEVEL

14. PART DEMOLISH WALL BETWEEN KITCHEN AND DINNING SPACE TO MAKE LARGER OPENNING. RETAIN 275 MM NIB TO WALL AND 200MM DOWNSTAND AT

15. REMOVE FRENCH DOORS AND REPLACE WITH LARGER FULLY GLAZED

16. CUT BACK NON ORIGINAL RUSTIC TIMBER FIREPLACE LINTLE TO BE FLUSH







