



CONSTRUCTION SEQUENCE

- 01 SET OUT PILES AND CAST PILES IN ACCORDANCE WITH ENGINEER'S DESIGN AND DETAILS
- 02 LOCALLY EXCAVATE TO PILE HEADS AND CAST 550 x 450 PILE CAPS
- 03 EXCAVATE TO MAXIMUM 1.5m BELOW GROUND LEVEL
- 04 INSTALL HORIZONTAL PROPPING TO PILE CAPS
- 05 EXCAVATE TO BASEMENT FORMATION LEVEL AND PREPARE SURFACE / INSTALL DRAINAGE /ETC
- 06 CAST AND CURE BASEMENT SLAB
- 07 REMOVE HORIZONTAL PROPPING TO PILE CAPS AND CONSTRUCT WALLS TO FACE OF PILES
- 08 CAST AND CURE LGF SLAB

JAMES FRITH LTD

CONSULTING CIVIL AND STRUCTURAL ENGINEERS  
+44 (0) 7876762553 | www.jamesfrithltd.com | office@jamesfrithltd.com

PROJECT: 15a PARLIAMENT HILL  
TITLE: TEMPORARY WORKS  
CONSTRUCTION SEQUENCE  
STATUS: FOR INFORMATION  
CLIENT: MH COSTA