



Date: 02.04.17

No: 303

| To: Hilary | Charlewood    |
|------------|---------------|
| All Saints | Church Fulham |

## DESCRIPTION Re. Flat 4, 17 Prince Albert Road, NW1 Firstly to take photographs of all remaining visible lath & plaster in situ. Client has also asked for photographs showing plasterboard sections already removed. Remove any damaged exiting laths, check fixings of remaining & secure as necessary. Remove any residual dust Using sawn chestnut laths, wet as appropriate before fixing at every joint with stainless steel nails ensuring a 6-10mm gap between each lath staggering at every 8th to prevent cracking. Dampen again Apply 8-10mm coarse lime putty plaster scratch coat & leave until green hard (can take several days) Dampen again before applying second floating coat of approx 8mm and leave to dry (less time needed than first) Dampen again before applying 1-2 topcoats of fine Photograph work progress regularly