



AKC Europe Ltd.

Registered address: 2 Sheen Road, TW9 1AE, Richmond, London

Showroom: Units 1-3, Wyvern Estate, KT3 4PH, Beverley Way, New Malden, Surrey

T: +44 (0) 208 949 5088

M: +44 (0) 7832 108 786

E: adam@akc-ltd.co.uk

W: http://akc-ltd.co.uk

METHOD STATEMENT – REMOVAL OF ALL DIRT AND GRIME FROM MASONRY

Client name:	Neil Morgan	Address of project:	47 Albert St, London, NW1 7LX
Quote/job number:	17002	Client contact:	Available upon request
Date project starts:	TBC	Expected finish date:	TBC
Scope of work:	Removal of all dirt and grime from masonry.	Drawing reference:	n/a
Nature of the site:	Multi dwelling residential.		
Site security/protection details:	Site will have hoarding installed all around and any access gates will be padlocked overnight, bolted during the day.		
Emergency procedures:	<ul style="list-style-type: none"> • The supervisor to ensure that a means of escape and rescue is provided throughout the duration of works. • All staff involved with the work to be instructed on the escape and emergency procedures. • If an electricity cable, gas pipe or high-pressure water main suffers any damage, however slight, the owner to be informed immediately and people to be kept well clear of the area until it has been made safe by the owner. 		
Site manager(s):	Lukasz Kotowicz	Names, roles and qualifications of staff completing work:	To be decided.
Tools and equipment: (list)	Chemicals: Bostik, cementone brick and patio clener. Hand tools:	PPE and safety equipment: (list)	High visibility clothing, safety boots, safety helmet and safety gloves.



AKC Europe Ltd.

Registered address: 2 Sheen Road, TW9 1AE, Richmond, London

Showroom: Units 1-3, Wyvern Estate, KT3 4PH, Beverley Way, New Malden, Surrey

T: +44 (0) 208 949 5088

M: +44 (0) 7832 108 786

E: adam@akc-ltd.co.uk

W: http://akc-ltd.co.uk

	Stiff brush, spray, watering can with a rose, wooden scrapers, fibre bristled brushes		
Work sequence:	<p>Work sequence:</p> <ol style="list-style-type: none"> 1. Erection of access scaffold. System access equipment to be used. Once scaffold has been built, it must be checked for stability. 2. Dry scrape off all areas of heavy contaminations using wooden scrapers. 3. Wet the surface to be cleaned with clean cold water. 4. Carefully apply the chemicals using fibre bristled brushes 5. After not less than 10 minutes, and not more than 30 minutes, thoroughly brush the surface with fibre bristled brushes. 6. In areas of stubborn staining it may be necessary to apply the chemicals a second time to obtain a clean surface. 7. When the work is completed site manager to inspect the work and sign a satisfaction note. 8. All equipment is thoroughly cleansed after use. 		
Method statement prepared by:	Adam Krefft (MSc Struct. Eng.) AKC Europe Ltd.	Signature:	Adam Krefft
Method statement agreed by:		Signature:	
Comments:	None.		