

NB - As a general rule we will set back the windows 100mm from the external face of the facade - All dims to be confirmed on site

Window Key: The WT is the window type with the window type number. The Next letters stand for where it occurs in the building, for example South elevation first and ground floor would read S01

REV.	AMENDMENT	BY:	DATE
1			

<p>14 Timber Frame Georgian style single hung sash window - Triple Glazed</p> <p>WT14-N10LG North elevation First floor Ground Floor</p> <p>First floor window section</p> <p>Note: on the ground floor this window has nothing behind it</p>	<p>15 Timber Frame Georgian style double casement window with fixed spandrel panel - Triple Glazed</p> <p>WT15-W10 West elevation First Floor Ground Floor</p> <p>Mock Georgian fixed window- spandrel panel mirror backed sealed and insulated behind</p>	<p>16 Timber Frame Georgian style single hung sash window - Triple Glazed</p> <p>WT16-WE1 West elevation East Elevation First Floor</p>	<p>17 Timber Frame Fixed window- Triple Glazed</p> <p>WT17-E1 East elevation First Floor</p>
<p>- EXISTING WALL - SEE DRAWING NO. 939 - 305 - EXISTING OPENING MOVED UP</p>		<p>- EXISTING WALL - SEE DRAWING NO. 939 - 301 - NEW OPENING 939 - 302 939 - 304</p>	<p>- EXISTING WALL - SEE DRAWING NO. 939 - 304 - NEW EXISTING OPENING</p>
<p>18 Timber Frame single casement window- Triple Glazed</p> <p>WT18-E1 East elevation First Floor</p>		<p>19 Timber Frame heritage style single hung centre bar sash window - Triple Glazed</p> <p>WT-E1-19 East elevation First Floor</p>	<p>20 Timber Frame Georgian style single hung sash window - Triple Glazed</p> <p>WT-S0-20 South Elevation Ground Floor</p>
<p>- NEW WALL - NEW OPENING</p>	<p>- EXISTING WALL - SEE DRAWING NO. 939 - 301 - EXISTING OPENING</p>	<p>- EXISTING WALL - SEE DRAWING NO. 939 - 304 - NEW OPENING 939 - 302</p>	<p>- EXISTING WALL - SEE DRAWING NO. 939 - 300 - EXISTING OPENING</p>

