

NB - As a general rule we will set back the windows 100mm from the external face of the facade
 - All dims to be confirmed on site

Window Key: The WT is the window type with the window type number. The Next letters stand for where
 it occurs in the building, for example South elevation first and ground floor would read S01

35 Timber Frame double casement
 Heritage style patio doors-
 Triple Glazed

Outward opening 4050
 2270
 2270

WT35-NB
 North Elevation
 Basement floor

36 Timber Frame double casement
 Heritage style patio doors-
 Triple Glazed

Outward opening 3210
 2270
 2270

WT36-NB
 North Elevation
 Basement floor

- NEW WALL
 - NEW OPENING

- SEE DRAWING NO
 939 -303

- NEW WALL
 - NEW OPENING

- SEE DRAWING NO
 939 -303

37 Timber Frame double casement
 Heritage style patio doors-
 Triple Glazed

Outward opening 3293
 2270
 2270

WT37-WB
 West Elevation
 Basement floor

38 Timber Frame double casement
 Heritage style patio doors-
 Triple Glazed

Outward opening 2025
 2270
 2270

WT38-WB
 West Elevation
 Basement floor

39 Timber Frame double casement
 Heritage style patio doors-
 Triple Glazed

Outward opening 2861
 740
 2270
 2270

WT39-EF
 East Elevation
 First floor

- NEW WALL
 - NEW OPENING

- SEE DRAWING NO
 939 -301

- NEW WALL
 - NEW OPENING

- SEE DRAWING NO
 939 -301

- NEW WALL
 - NEW OPENING

- SEE DRAWING NO
 939 -302

