

The crew will need to board out the lead roof with tarp protection & plyboards. Debris that are extracted through the Cereform will have to be cut up into small bundles and sympathetically carried through the gate yard.

