

## STAGE 1:

INSTALL LATERAL PROPS AND SHORES AT LOW LEVEL. BREAK OUT EXISTING GROUND BEARING SLAB AND LOWER GROUND FLOOR BY 1250mm



