

INSERT HELIFIX 6mm AUSTENITIC STAINLESS STEEL BARS ACROSS EACH CRACK, EXTENDING A MIN OF 500mm BEYOND THE CRACK @ EVERY 4th COURSE. WHERE THE CRACK EXTENDS THROUGH A PIER, THE MORTAR BED OF THE PIER TO BE RAKED OUT TO ALLOW THE HELI BAR TO CONTINUE THROUGH THE PIER TO 500mm BEYOND IT. MORTAR BED TO BE GROUDED UP AND MADE GOOD WHEN HELI BAR IS IN PLACE. MAKE GOOD ALL VERTICAL CRACKS WITH CRACKBOND TE, AN EPOXY-BASED WEATHERPROOF FILLER. RE-POINT THE MORTAR BED AND MAKE GOOD.

TO BE INSTALLED STRICTLY IN ACCORDANCE WITH MANUFACTURES INSTRUCTIONS

WINCHESTER Rd NW3

WINCHESTER ROAD

INSERT HELIFIX 6mm AUSTENITIC STAINLESS STEEL BARS ACROSS EACH CRACK, EXTENDING A MIN OF 500mm BEYOND THE CRACK @ EVERY 4th COURSE. WHERE THE CRACK EXTENDS THROUGH A PIER, THE MORTAR BED OF THE PIER TO BE RAKED OUT TO ALLOW THE HELI BAR TO CONTINUE THROUGH THE PIER TO 500mm BEYOND IT. MORTAR BED TO BE GROUDED UP AND MADE GOOD WHEN HELI BAR IS IN PLACE. MAKE GOOD ALL VERTICAL CRACKS WITH CRACKBOND TE, AN EPOXY-BASED WEATHERPROOF FILLER. RE-POINT THE MORTAR BED AND MAKE GOOD.

TO BE INSTALLED STRICTLY IN ACCORDANCE WITH MANUFACTURES INSTRUCTIONS

WINCHESTER ROAD