

EXISTING LOWER GROUND FLOOR/ GARDEN FLOOR PLAN

PRELIMINARY TRIAL HOLE EXCAVATIONS

Excavate to expose existing brick spreader courses only. When lowest course is found remove soil from beside it only for a distance of around 50cm in both directions. Do not excavate below the level of any brickwork or into any compacted soil/gravel layer that may be encountered below the brickwork. Clients appointed Structural Engineer to advise on any further exposure works on site

DRAINAGE

Lift existing manhole covers and check drain runs together with depths to invert

