notes on windows in Mews

- remove existing boading and replace with lead
- remove existing modern metal windows and replace with new sash windows with traditionally detailed painted timber double glazed windows





est Architecture
iit 319
recenworks
Highbury Grove
ndon, NS ZEF
0
lephone +44 (0)203 859 0211
mail Info@westarchitecture.co.uk

General Notes on Repairs:

Brickwork

- Carefully rake out damaged joints and re-point where necessary in matching mortar.
- Carefully brush clean brickwork to remove moss and staining where necessary.
- Replace mismatching brickwork with second hand bricks to match existing sample must be approved by Architect
- Soot down any repairs to match existing.

Stone


 Carefully brush clean stonework - remove moss and stain and repoint as necessary.

Leadwork

 Carefully investigate roof leadwork once safe access is established, and repair/replace as necessary all in accordance with Lead Sheet Association's recommendations.

Drainage

- Remove redundant services.
- Repair/replace damaged pipes as necessary.
- Clear all the blockages
- All the external rainwater and soil vent pipes are to be replaced in cast iron to match existing.
- All internal soil vent pipes must be adequately sound insulated and properly concealed, and to follow existing service route where possible.



PROPOSED MEWS ELEVATION

Project JOHN STREET	Job No	880	Drg No	88.210	Rev P1
Title PROPOSED MEWS ELEVATION	Scale	1:125	Date	22.05.20	Sheet A3
	Client	JB		Drawn hm	Check gw
Illustrated material subject to conviging					

Illustrated material subject to copyright dimensions to be checked on site and errors to be reported to architect