















NOTE: PLEASE BE AWARE, YOUR FINISHED FLOOR TO UNDERSIDE OF FINISHED BULKHEAD HEIGHT MUST BE BUILT TO THE EXACT DIMENSIONS SHOWN ON THIS DRAWING TO ENABLE SUCCESSFUL DOOR INSTALLATION.