The Conservation Rooflight[®] Between the Rafter Roof Window Sizes and Prices


Before selecting your size, carefully read the 'Installation Overview' PDF.



uctural Area internal imeter of the rture - the frame the roof window. ase measure the th and length he edge of the



Viewable Area The area of glass that is viewable from inside the room. Please measure the width and length at its closest point to the glass.



PLEASE NOTE: THE DIFFERENCE BETWEEN AN 'ON THE RAFTER' OR 'BETWEEN THE RAFTER' ROOF WINDOW

□ Egress Conservation Rooflights®