

Do not scale this drawing.
 For structural dimensions and details see Structural Engineers drawings.
 All dimensions to be checked on site proir to commencement of any works.

4. All errors in co-ordinates, levels and dimensions, are to be reported to the Architect.
5. All temporary works to be responsibility of the contractor.
6. This drawing to be read in conjunction with all relevant Architect's drawings and specifications and with other Consultant's Information.

or preperation of any shop drawings.

PLANNING