

Sedum Roof Maintenance

A sedum roof only requires maintenance a few times a year. The optimum times for maintenance are spring and early autumn. Sedum roofs can be walked on during maintenance. Walking on sedum roof should be avoided when there is a frost.

Safety helmets to be worn, fall protection clothing and harnessing utilised. Inspections should be made a minimum of twice a year for possible weeds carried by the wind and unwanted vegetation both of which can be removed by hand. Additionally rainwater drains and gutters should be checked and any leaves or other blockages removed.