

CHECKED BY PM

29/04/2024

REV

THE CONTRACTOR IS TO CHECK AND VERIFY ALL BUILDING AND SITE DIMENSIONS, LEVELS AND SEWER INVERT LEVELS AT CONNECTION POINTS BEFORE WORK STARTS. DO NOT SCALE FOR CONSTRUCTION PURPOSES