

Existing Roof Plan and Section

PLANNING

Use figured dimensions only.
Do not scale from this drawing.
All levels and dimension to be checked on site by contractor. Any discrepancy to be ventiled by the Architect before proceeding.
Drawing to be read in conjunction with all relevant JRPA drawings and specification clauses.
The Contractor and relevant fabricated products to be built to current British and European Standards. This drawing must not be used for Land Transfer unless stated as 'Conveyance'.

This drawing and its subject matter are the confidential property of John Rowe-Parr Architect and shall not be copied, reproduced, used or disclosed to others without the prior written authority of John Rowe-Parr Architects.

1:50 @ A1

18 April 2011

John john@johnroweparr.co.uk

drawing number L11.748.03

161 Rosebery Avenue London. EC1R 4QX Tel: 020 72788488 Fax: 020 72784388 jrpa@johnroweparr.co.uk A R C H I T E C T S