

_	
8th Floor	
7th Floor	
6th Floor	
5th Floor	
4th Floor	
3rd Floor	
2nd Floor	
1st Floor	
Grd Floor	
Basement	

North Elevation

South Elevation

NOTE : WHEN PRINTING PDF PLANS, ALWAYS ENSURE THAT PAGE SCALING (IN PRINTER DIALOGUE BOX) IS SET TO <u>NONE</u>. USING FIT TO PAGE WILL INTRODUCE SCALING ERRORS.

0m 5m 10m

