



1-6 Pratt Mews, London, NW1 0AD

Loading & Unloading Diagram



PRATT STREET



PRATT MEWS

Vehicles will not be permitted or able to enter or exit Pratt Mews while deliveries are taking place. Traffic Marshals will prevent other vehicle entering Pratt Mews during this time.

Removable section of hoarding during demolition to allow skips and bins to be removed and delivered.

Removable section of hoarding will also be used for deliveries to and from site.