


GROUND FLOOR
1:100@ A3

INDICATIVE AREA FOR SITE MATERIAL STORAGE / BUFFER ZONE:
36m² area (6.5m x 5.5m) allowing for Contractors site set up, material
and equipment keeping 6m clearance for protection of Tree root zone

INDICATIVE FENCE POSITION: To remain in position throughout
construction of extension in order to protect tree root zone

INDICATIVE TREE ROOT ZONE: Calculation based on tree
height, stem size and adjacent surroundings.

T1
6000
TREE ROOT ZONE
CALCULATION BASED ON HEIGHT, STEM SIZE
AND ADJACENT CONTEXT.



0 1 2.5 5 10m

Scale 1:100