
G1 For Site and Grid setting out refer to AXXXX/3000 G2 All dimensions to be checked on site G3 Any discrepandes between drawings to be reported to the Architect immediately, G4 All Levels are above ordinance datum (AOD) New Levels are above thus: Existing Levels are shown thus: EX-20: Retained Existing Levels: GENERAL NOTES:

G10 Door(D) & Window (W) References Door No. /DLG-006 60 Fire Rating R402 -G8 For elements of work subject to Contractor's Design, this drawing is indicative of the "sual & performance regularments only. The Contractor is responsible for the desided design and co-ordination of the installation within the parameters defined in the specification, design drawings, contract terms and contract documents. G7 For tolerances see the Design Drawings and Specifications G6 Refer to Engineers drawings for all structural and services information. G11 Clear height is shown thus (finished floor to finished soffit) G5 Use figured dimensions only: Do not scale from drawings. IF IN DOUBT, ASK. G9 Room numbers are shown thus: G13 Finishes are shown thus: G12 T Sheet Reference shown thus G14 Setting Out Points shown thus: Door Type \IWS-01\ \$75Ø (115) Ironmongery Type



A/1SR	Sort Code	Scale: 1	
1020	Drawing No.	1 : 100 @ A3	
П	Revision		

1 Spencer Rise

© EDWARD WILLIAMS ARCHITECTS LTD. reg. in England No. 4342513 reg. office The Pines Boars Head Crow