



notes:

5m 2m 1m 0.5m

immediately

any discrepancies should be reported immediately

commencement of work

identified in the product

investigation or inspection.

all dimensions should be checked on site prior to

(www.promap.co.uk) prodat does not guarantee that all past or current uses or features will be

or taken to indicate or exclude actual suitability or unsuitability of the site for any particular purpose, or relied upon for determining salability or value,

site/survey based on ordnance survey information provided by prodat systems plc,

the product does not give details about the actual state or condition of the site nor should it be used

or used as a substitute for any physical

dwelling emission rate (der/ter) calculation. the

© HERTFORD PLANNING SERVICE

criteria set for air permeability.

when printing off pdf's.

note

sized sheet.

correctly.

drawings to be read in accordance with the

building must be built 'as designed' meeting the

it is the responsibility of the user to verify that the resulting prints are to scale on the appropriate

also that the scale bars on the plan measure