


PLANNING
ractor must check dimensions on site. Only figured dimensions to d from.
repancies must be reported to the architect before proceeding.
This drawing is © copyright Platform 5 Architects llp



REVISION:

050