

## ANS Global 'Grufetile' Installation and Maintenance

### *Installation*

- A protection fleece is laid over the roof membrane
- Pre-grown trays are laid onto protection fleece and clipped together. Trays can be cut to size if required.
- Edging profiles are installed if required.

### *Maintenance*

The Grufetile roof is a low maintenance system. It is irrigated by rainwater only and does not require any specific maintenance regime. The sedum will survive throughout the year, with the wildflowers and grasses appearing late spring to early autumn. If for any reason specific plants need to be replaced, this can be done in situ or the trays can be temporarily removed from the roof and then reinstated.