

Door Schedule

Flanagan Lawrence

66 Porchester Road
London
W2 6ET
United Kingdom

T +44 (0) 207 706 6166
F +44 (0) 207 706 6266
E info@flanaganolawrence.com

www.flanaganolawrence.com

Refurbishment of Grade II* Listed Office Building

6 Bloomsbury Square
London
WC1A 2LP

Planning – Additional info Issue: July 2015

Prepared on behalf of:

Danny Ungar
South Bloom Ltd.
14 Cavendish Place
London
W10 9DJ

Note: This schedule to be read with drawings A-30-099, A-30-100, A-30-101, A-30-102, A-30-103

Door Schedule

Flanagan Lawrence



General

- Remove existing paint
- Repaint
- Repair damage to frames
- Take site dimensions for all new doors
- Condition of original doors
 - A- Good condition
 - –Remove paint, existing hardware and signage
 - - Repaint (PTS-131) install new hardware
 - B-Average
 - As above + repair small cracks
 - C- Bellow average
 - As above + repair large cracks
 - D-Poor
 - As above + repair holes in door, panels coming away from frame

	New Door
--	----------


Door Schedule

Flanagan Lawrence

Door	Type	New /Existing	Description /condition	Material	Opening size	Finish	Vision Panel	fire rating	Ironmongery	
D.B.1	E.4	N	external - Vault	timber		Painted	N	-	Set 1	
D.B.2	-	E	Remove	-			-	-	-	-
D.B.3	E.4	N	External-Vault	timber		Painted	N	-	Set 1	
D.B.4	E.2	N	External – Georgian Pannel <i>*Revised as advised by Camden Council</i>	timber	830x1940	DRT-291	Y		Set 2	
D.B.5	I.7	N	Portman P7001 ID - Pocket Door	timber	800x2000	PTS-131	N	-	Set 8	
D.B.6	I.7	N	Portman P7001 ID - Pocket Door	timber	900x2000	PTS-131	N	-	Set 8	
D.B.7	I.6	N	internal - Georgian	timber	910x1980	PTS-131	Y	FD30S	Set 3	


Door Schedule

Flanagan Lawrence

D.B.8	I.7	N	Portman P7001 ID - Pocket Door	timber	900x2000	PTS-131	N	-	Set 8	
D.B.9	I.4	E	Strong Room	steel		PTS-131	N	FD30S	Set 7	
D.B.10	-	E	Remove	-			-	-		-
D.B.11	I.2	E	internal - Georgian	timber	970x1980	PTS-131	N	FD30S	Set 3	
D.B.12	I.6	N	internal - Georgian	timber	760x2000	PTS-131	Y	FD30S	Set 4	
D.B.13	I.6	N	internal - Georgian	timber	To be created in wall to match 900x2000	PTS-131	Y	FD30S	Set 3	
D.B.13. A	E.3	N	external - modern	steel, glass	Using existing opening of two existing windows and cutting down to FFL		Y	FD30S	Set 6	

Door Schedule

Flanagan Lawrence

D.B.14	E.2	N	external - Georgian	timber, glass	1020x1990	DRT-291	Y	-	Set 5	
D.B.15	I.5	N	internal - Georgian	timber	790x1800	PTS-131	N	-	Set 4	
D.B.16	I.5	N	internal - Georgian	timber	790x1800	PTS-131	N	-	Set 4	
D.0.1	E.1	N	external - Georgian	timber	1150x2180	DRT-201	N		Set 10	
D.0.2	I.1	N	internal double	timber, glass	1680x2130	PTS-131	Y		Set 9	
D.0.3	I.2	E	Original/B	timber	930x2000	PTS-131	N	FD30S	Set 3	
D.0.3.A	I.8	E	Under stair	Timber	760x1790	PTS-131	N		Set 11	

Door Schedule

Flanagan Lawrence

D.0.4	I.2	E	Original/B	timber	930x1980	PTS-131	N	FD30S	Set 4	
D.0.5	I.2	E	Original/C	timber	960x1970	PTS-131	N	FD30S	Set 3	
D.0.6	I.6	N	internal - Georgian	timber	850x1980	PTS-131	Y	FD30S	Set 3	
D.0.7	I.5	N	internal - Georgian	timber	To be created 900x2000	PTS-131	N		Set 4	
D.0.8	I.2	E	internal - Georgian	timber	770x1980	PTS-131	N		Set 4	
D.0.9	I.2	E	Original/A	timber		PTS-131	N		Set 4	



Door Schedule

Flanagan Lawrence

D.1.1	I.2	E	Original/C	timber		PTS-131	N	FD30S	Set 3	
D.1.2	I.5	N	internal - Georgian	timber	780x1950	PTS-131	N	FD30S	Set 4	
D.1.3	I.2	E	original	timber	890x1960	PTS-131	N	FD30S	Set 3	
D.1.4	I.6	N	internal - Georgian	timber	890x1990	PTS-131	Y	FD30S	Set 3	
D.1.5	I.2	E	Original/A	timber	To be created 900x2000	PTS-131	N		Set 4	
D.1.6	I.2	E	Original/D	timber		PTS-131	N		Set 4	

Door Schedule

Flanagan Lawrence

D.1.7	I.7	N	Portman P7001 ID - Pocket Door	timber	725x2000	PTS-131	N		Set 8	
D.1.8	I.7	N	Portman P7001 ID - Pocket Door	timber	725x2000	PTS-131	N		Set 8	
D.1.9	I.3	E	original double/C	timber		PTS-131	N		Set 12	
D.2.1	I.5	N	internal - Georgian	timber	980x1980	PTS-131	N		Set 4	
D.2.2	I.5	N	internal - Georgian	timber	190x1970	PTS-131	N		Set 4	
D.2.3	I.2	E	original	timber	850x1950	PTS-131	N	FD30S	Set 3	
D.2.4	I.2	E	original	timber	844x1990	PTS-131	N	FD30S	Set 4	



Door Schedule

Flanagan Lawrence

D.2.5	I.6	N	internal - Georgian	timber	910x1990	PTS-131	Y	FD30S	Set 3	
D.2.6	I.6	N	internal - Georgian	Timber	950x2000	PTS-131	Y	FD30S	Set 3	
D.2.7	I.5	N	internal - Georgian	Timber		PTS-131	N		Set 4	
D.2.8	I.5	N	internal - Georgian	Timber	910x1990	PTS-131	N		Set 4	
D.2.9	I.7	N	Portman P7001 ID - Pocket Door	Timber	725x2000	PTS-131	N		Set 8	
D.2.10	I.7	N	Portman P7001 ID - Pocket Door	Timber	725x2000	PTS-131	N		Set 8	
D.2.11	I.5	N	internal - Georgian	Timber	980x1970	PTS-131	N		Set 4	

Door Schedule

Flanagan Lawrence

D.3.1	I.6	N	internal - Georgian	Timber	770x1860	PTS-131	Y	FD30S	Set 4	
D.3.2	I.2	E	internal - Georgian	Timber	770x1840	PTS-131	N	FD30S	Set 3	
D.3.3	I.2	E	internal - Georgian	Timber	870x1880	PTS-131	N	FD30S	Set 3	
D.3.4	I.6	N	internal - Georgian	Timber	860x1900	PTS-131	Y	FD30S	Set 3	
D.3.5	I.5	N	internal - Georgian	Timber	790x1860	PTS-131	N		Set 4	
D.3.6	I.7	N	Portman P7001 ID - Pocket Door	Timber	725x2000	PTS-131	N		Set 8	
D.3.7	I.7	N	Portman P7001 ID - Pocket Door	Timber	725x2000	PTS-131	N		Set 8	

Door Schedule

Flanagan Lawrence

 D.3.8	I.5	N	internal - Georgian	Timber	760x1870	PTS-131	N		Set 4	
--	-----	---	------------------------	--------	----------	---------	---	--	-------	---