

### **NBS SECTION Q37 - DESCRIPTION OF WORKS**

Section Q37 deals with the design and installation of the Bauder Green Roof landscaping system, including the various related elements i.e. separation, protection, and drainage layers, substrates, Bauder supplied planting and accessories such as inspection chambers, trims etc. It invokes clauses from related sections for waterproofing, insulation, landscaping and maintenance as necessary for a complete system.

It is intended for use on projects where the detailed design is completed by the specifier (architect or landscape architect) with technical assistance from the manufacturer as required and should be read in conjunction with any project specific drawings provided.

## **SCOPE OF WORKS**

## This section includes:

- Bauder Extensive Green Roof System components/ landscaping
- Bauder Intensive green roof system components/ landscaping.
- Related Bauder system accessories

### This section does not include:

- Construction of the structural deck
- Bauder waterproofing system refer NBS Section J41-110C.
- Irrigation refer NBS section S\_\_\_.
- Kerbs / edgings, channels/ paving accessories refer NBS section Q10.
- Granular sub-bases to roads / paving refer NBS section Q20.
- Interlocking brick / block roads / cobble paving refer NBS section Q24.

## Q37 GREEN ROOFS

To be read with Preliminaries / General Conditions.

#### **GENERAL**

# 110 INTENSIVE GREEN ROOF

- Roof Area: Basement Roof Below External Works (Type 7)
- · Landscape finish: Intensive Hard Landscaping
- Substrate: New Structural Concrete Deck

**Note:** The loading of the proposed green roof system/landscaping needs to be accounted for in the design and construction of the structural deck, both during construction and then after.

- Slope: 1:60
- Waterproofing System: BAUDER TOTAL ROOF SYSTEM SYSTEM as per J41-110E
- **Slip Layer:** Bauder PE Foil (loose laid) rolled out in two layers, with sheets staggered. Installation as clause 745.
- **Protection/drainage layer:** Bauder FSM1100 8mm protection fleece. Installation as clause 750C.
- Water storage/drainage layer:
  - Bauder Attenuation Cell 100, thickness 100mm. Installation as clause 770D.



- Bauder DSE60 60mm drainage / water storage panel. Installation as clause 770l.
- **Board fill:** 2-5mm crushed and washed angular gravel aggregate (no fines) supplied by others as granular fill. Installation as clause 775A.
- **Bedding layer (hard landscaping):** 2-5mm crushed and washed angular gravel aggregate (no fines) bedding layer. Installation as clause 832A.
- Landscaping depth: TBC
- **Surfacing: Paving slabs:** Supplied by others to the landscape designers requirements as clause 465, installed on to the specified gravel bedding layer (refer 832A). Installation of the paving as clause 841B.
- Accessories: Bauder GA250 rainwater access cover.

  Size: 250 x 250 mm. Features removable grille plate, gravel guard surround and adjustable feet (height adjustment range 65 mm to 100 mm), that is suitable for most situations. Installation, as clause 830A.
- Additional requirements: 210, 710, 715A, 720, 910, 920, 930.

## 130 EXTENSIVE GREEN ROOF:

- Roof Area Name: Level 5 Roof Terrace/Green Roof
- Landscaping finish: Extensive Green Roof Landscaping
- Substrate: New Concrete Deck
- Slope: Level
- Waterproofing system: BAUDER TOTAL GREEN ROOF SYSTEM refer Section J41-110C.
- Slip Layer: N/A
- **Protection layer:** Bauder FSM600 4mm protection fleece. Installation as clause 750C.
- Water Attenuation Layer: Bauder Attenuation Cell 100, thickness 100mm. Installation as clause 770D.
- Drainage layer: Bauder DSE40 drainage / water storage panel. Installation as clause 770E.
- Filter membrane: Bauder Filter Fleece. Installation as clause 780A.
- **Growing Medium:** Bauder Biodiverse Substrate, depth 100mm above the filter fleece. Installation as clause 790A.
- Landscaping depth: TBC
- Vegetation: Bauder Flora 5 seed mix. Installation as Clause 801D.
- Sufacing Paving slabs and support pedestals for paving: Paving to be supplied by others to the landscape designers specification (as clause 465), installed on the Bauder Pedestal Support System (refer Clause 835). Installation of paving as clause 841A

#### Accessories:

- Project specific drip line irrigation system (designed and supplied by others), as clause 463A. Installation of irrigation pipe work to the waterproofing as clause 825.
- Bauder AL150 drainage and retention trim, fitted to all open perimeters to contain a pebble vegetation barrier. Installation as clause 820B.
- Bauder ALU 250 Inspection chamber, to be installed over all internal rainwater outlets within soft landscaping areas. The lid of the chamber must be level with, or higher than the surrounding landscaping. For landscaping exceeding 100mm, additional height adapter units (available in 50mm or 100mm depths) must be used to achieve the required chamber depth, with the chamber lid being at least level with the surrounding landscaping or higher. Installation as clause 830.
- Bauder GA250 rainwater access cover.
  - **Size:** 250 x 250 mm. Features removable grille plate, gravel guard surround and adjustable feet (height adjustment range 65 mm to 100 mm), that is suitable for most situations. Installation, as clause 830A
- Bauder KH60 linear drainage channel, supplied with grille plate only. Installation as



clause 830C

- Purpose made gravel guard for Bauder Parapet Emergency Overflow, pre-fabricated from perforated stainless steel (fabricated and supplied by others). Refer clause 830F.
- 20 40mm round washed pebble vegetation barrier provided around all protrusions and in conjunction with AL150, where used at perimeters, as clause 460. Installation as clause 840.
- Additional requirements: As clauses 210, 710, 715A, 720, 910, 915D, 916, 920, 930.

#### **PRODUCTS**

## **460 PEBBLE BALLAST**

- Type: Washed, round pebbles.
- Size: Graded 20-40mm and free from fines and sharps.
- Supplier: Locally sourced.

## **463A IRRIGATION**

- Supplier: Access Irrigation Ltd. Crick, Northampton NN6 7XS
   Tel: 01788 823811, Fax: 01788 824256, E-mail: <a href="mailto:sales@access-irrigation.co.uk">sales@access-irrigation.co.uk</a>
- **Product reference:** Permadrip Pro drip line irrigation system with anti-syphon design to resist clogging and pressure regulation.
- Material: Perforated UV resistant plastic Colour: Dark Brown
- **Height**: 10mm
- **Operating range:** 0.8 -4.3bar.
- Wall thickness: 1.2mmNozzle output: 1.6L/h
- Spacing: 150mm.
- **Pipe connection:** For Bauder Green/Blue Roofs, all irrigation systems using Permadrip Pro must use PoziLock compression fittings for both the dripline and water feed pipework. Barbed connectors are not permitted.
- Location:
  - Bauder Vegetation Blankets: Irrigation system to be installed flush with the surface of the vegetation blanket and tested to ensure that it is fully operational.
  - Bauder Plug Plants, Flora Seeded Systems & Biodiversity: Irrigation system to be installed flush with the surface of the growing medium and tested to ensure that it is fully operational prior to installation of the vegetation.
- Design: The design, water pressure, positioning and spacing of the drip line is critical to the
  performance and effectiveness of the system. Therefore, the irrigation scheme for each
  project should be designed accordingly to ensure it is fit for purpose. Irrigation is a specialist
  subjects and Access Irrigation Ltd provide a design service and can assist with information
  pertaining to any individual project upon request.
- **IMPORTANT NOTE:** These are permanent irrigation systems and do not negate the need for the establishment watering regime.

## 465 PRECAST CONCRETE PAVING SLABS

- **Standard:** To BS 7263-1, hydraulically pressed.
- Manufacturer: \_\_\_\_\_.
- Product reference: .
- Colour/ Finish: \_\_\_\_\_.
- Size: .



Recycled content: \_\_\_\_\_\_\_.

### **EXECUTION**

### 710 INSTALLATION GENERALLY

- Preparation: Clear all surfaces of debris.
- **Timing:** After certification of waterproof membrane integrity.
- **Surface condition:** Visually inspect waterproof membrane, report any damage.
- Faults in waterproof membrane: Report.
- Contamination: Do not use materials detrimental to healthy plant growth.
- Storage: Do not overload.
- Point loads: Avoid.
- Outlets: Do not block.
- Outlet grilles: Installed (these can be omitted where Bauder inspection chambers are used, if the grille cap height obstructs the closing of the chamber lid).

### 715A LANDSCAPED ROOF RELATED REQUIREMENTS

- The following are vital to the accurate pricing, correct installation, and ultimately the long-term life of a green/blue roof, and must, therefore, be included within the specification and tender documents: -
- **Loadings:** It is assumed that the architect or his advisors have satisfied themselves that the roof structure and deck are suitable to receive the dead load of the proposed green/blue roof system and landscape both during construction and on completion of the works.
- Additional protection: A planned or contractual delay between the installation of the waterproofing and landscape will almost certainly necessitate additional/increased protection to the waterproofing. This protection may be temporary or permanent. The responsibility and cost of this possible extra protection should be clearly included within the tender documents.
- Detailed drawings: Correct detailing design and construction is essential to the long-term life
  of the green/blue roof. It is essential, therefore, that detail drawings illustrating for the
  construction are included with the tender documents, in order to enable the contractor to
  tender accurately.
- **Minimum upstand height requirements**: The waterproofing should be taken up all abutment upstands, pipes, detailing protrusions etc. a minimum of 150mm above finished landscape surface level to comply with British Standards and current code of practice BS8217:2005.
- Provision for living products in hot weather conditions: During hot weather conditions, living products such as plants, turf, sedum blankets etc. must be laid on the day of delivery to site. With regard to sedum blankets or turf, any rolls not installed should be laid out and kept watered prior to final installation.
- Watering / Irrigation: Initial watering should be by surface sprinklers to ensure that the plants
  are kept moist until established. Adequate provision for watering the installed planting must be
  in place on site before the product is installed. Irrigation systems if fitted should be operational.
  Surface sprinklers should be used to water in the fertiliser. All watering should be carried out in
  strict accordance with the Bauder watering requirements and guidance document.
- **Final Inspection:** No landscaping work should be installed until Bauder have carried out a final inspection to the waterproofing and have passed this as suitable for guarantee. It is the responsibility of the roofing contractor to advise and organise this inspection with Bauder. We cannot guarantee any waterproofing that has been landscaped without this inspection having been carried out and passed as acceptable.

**Please note**, there are/maybe further 'sign-off' inspections required to complete the roof(s) for this specification.



## • Sign-off Inspections:

**Bauder Extensive Green Roofs:** Bauder Extensive or Biodiverse soft landscaped green roof installations require an inspection and it is the responsibility of the installing contractor to inform Bauder Ltd when the installation has been completed.

**Bauder Blue Roofs:** Landscaped roofs designated as 'Blue Roofs' and featuring outlets fitted with Bauder Blue roof flow rate restrictors, must be inspected and signed off by Bauder. This is to ensure correct installation of integral 'Blue Roof' components. Safe access to carry out this inspection must be provided.

- Damage risk form other trades: No landscaping should be installed while the roof area is subject to other site traffic. Bauder will carry out an inspection of the completed roof 4-6 weeks following installation and any site related damage by others will be reported to the client. Bauder accept no responsibility whatsoever for damage to the product or the installation caused by site work carried out by others after the landscaping has been installed.
- **First year maintenance:** The contractor must price into his tender the cost of post installation maintenance for a minimum period of 1 year to ensure the handover of a flourishing soft landscaped roof.

## 720 ADVERSE WEATHER

- Unfinished work: Secure from damage and wind uplift.
- Conditions: Do not install or work with frozen materials.

## LANDSCAPING INSTALLATION

#### 745 SLIP LAYER INSTALLATION

- **Installation**: to be rolled out loose over the root resistant layer as specified (one layer for Extensive landscaping and two layers for Intensive landscaping).
- This product is only required for roofs with a fall between 0-3° (A slip layer is not necessary or advisable for slopes above 3°).
- Joints: Minimize.
- Overlaps (minimum): All laps to be 150mm with care being taken to ensure that roll sides join between layers.
- **Upstands:** Extend to top of growing medium. Sufficient foil must be allowed for to enable it to be taken up all upstand and edge details prior to installation of the protection layer.

## 750C PROTECTION LAYER INSTALLATION

- **Installation:** Protection fleece rolled out and laid loose. Laps to be sealed by lightly heating overlap area with a propane gas torch / hot air welding gun to melt the polypropylene fibres and then press seal the two fleece sheets together.
- Joints: Minimize.
- Overlaps (minimum): Laps to be 150mm
- Upstands: Sufficient protection fleece must be allowed for so that it may be installed to all abutment upstands and edge details, in accordance with the manufacturer's instructions. Extend to full height of the upstand and secure in place by using a lead or fabricated metal counter-flashing.
- Outlets: Should be trimmed well back from ALL outlets.
- Openings in landscape restraint kerbs: Where these kerbs are present (roof slopes above 5°), the protection layer should be cut away from the openings/ gaps to avoid impeding drainage.

# 770D WATER ATTENUATION LAYER INSTALLATION



- Extent: Continuous over designated roof area.
- **Fitting:** Loose laid over the protection layer. Boards are to be butt jointed and clipped together using cross connectors (ordered separately).
- **Upstands:** Carefully cut to fit closely around penetrations and outlets, cutting the panel where required.
- **Multiple layers:** Loose laid over the previous layer. The boards are to be close butted and connected together using 'Shear Connectors'.

## 770E DRAINAGE / WATER STORAGE LAYER INSTALLATION

- Extent: Continuous over entire designated roof area.
- **Fitting:** Loose laid over the protection layer. Boards to overlap and interlock by one cup profile at sides and ends and each row be laid staggered. The 'X' stamped impression on the highpoint of the cup moulding indicates where boards overlap.
- **Upstands:** Carefully cut to fit closely around penetrations and outlets.
- Construction of planter walls: The drainage/water storage board provides a suitable base surface for building concrete or brick kerbs/walls. The specified infill haunching should be installed over the board to required depth of cover, poured directly into the cells of board. These should be constructed to provide an adequate support for the raised masonry planters For the specification of the type of infill and all kerb/wall construction elements please refer to the structural engineer's plans and the specification. An internal surface of the planter wall may be primed using bituminous primer and then lined with single layer of torch applied Bauder root resistant capping sheet. The bright green slate finish may be considered undesirable, but the slate is necessary for long-term UV protection of the bitumen. To disguise and blacken the slate colour, paint exposed areas above anticipated soil level with a light coat of bituminous primer.

#### 770I DRAINAGE / WATER STORAGE LAYER INSTALLATION

- Extent: Continuous over entire designated roof area.
- **Fitting:** Loose laid over the protection layer. Boards are to be tightly overlapped at the edges and staggered.
- **Upstands:** Fit closely around penetrations and outlets.
- Construction of planter walls: The drainage/water storage board provides a suitable base surface for building concrete or brick kerbs/walls. The specified infill haunching should be installed over the board to required depth of cover, poured directly into the cells of board. These should be constructed to provide an adequate support for the raised masonry planters For the specification of the type of infill and all kerb/wall construction elements please refer to the structural engineer's plans and the specification. An internal surface of the planter wall may be primed using bituminous primer and then lined with single layer of torch applied Bauder root resistant capping sheet. The bright green slate finish may be considered undesirable, but the slate is necessary for long-term UV protection of the bitumen. To disguise and blacken the slate colour, paint exposed areas above anticipated soil level with a light coat of bituminous primer.

### 775A GRANULAR FILL

- Extent: Continuous over designated roof area.
- **Installation:** Applied directly to the water storage/ drainage board, filling the cellular troughs to a level flush with the upper crowns of the board and eliminating any hollows. Allowance should be made for any settlement that may occur.
- In soft landscaped situations where a vegetation barrier is to be installed (inspection chambers at outlet positions, perimeters, roof penetrations etc.), the granular fill should be stopped



500mm short of the abutment and substituted with the 20/40mm round washed pebbles used to create the vegetation barrier (see standard detail drawings).

- Depending on size and access of the project, the specified granular fill can be supplied by the manufacturer by various methods i.e. big bags, Tipper truck or via a silo lorry pumping directly onto the roof area.
- Prior to costing this element of the installation the 'Approved Contractor' should contact Bauder Ltd so that they may help to advice on the best solution, specific to any contract.

### 780A FILTER MEMBRANE INSTALLATION

- **Joints:** Minimize.
- Overlaps (minimum): 150mm
- Fitting: Loose laid over drainage layer in accordance with manufacturer's recommendation.
- **Upstands (soft landscaping):** Extend up, between vegetation barrier and growing medium and trim flush with finished surface level.
- **Upstands (Hard landscaping):** Extend to top of perimeter abutments and trim flush just below finished surface level.

## 790A GROWING MEDIUM INSTALLATION

- Handling: Minimize.
- Conditions: Handle in the driest condition possible. Do not handle or install when wet or frozen.
- Layers: Start by applying two equal layers, building up to required maximum depth.
- Sequence: Gently firm each layer before spreading the next. Allowance should be made for any settlement that may occur. It is recommended that measuring stick markers of the required depth be used around the roof area to ensure that a minimum acceptable thickness of growing medium is achieved.
- **Supply:** Depending on size and access of the project the 'substrate' can be supplied by various methods i.e. Tipper, Silo lorry (pumping directly onto the roof area), Big bags, or sacks. Prior to costing this element of the installation the 'Approved Contractor' must contact Bauder Ltd so that they may advise on the best solution on any specific contract.
- Important note regarding alternative substrates: If alternative substrates are required (e.g. topsoil...etc.), Bauder does not take any responsibility for the performance of such substrates supplied from an alternative source. We recommend that alternative substrates should be covered by a technical data sheet and certified in writing as suitable to support the system and plants specified. Saturated weight loadings must be provided directly from the supplier of the substrate and should be the subject to a structural engineer's approval.

### 801D BAUDER FLORA SEED MIXES

- General: The ideal time for seeding is in the spring and autumn. Please note that increased
  post installation aftercare will be required for installations that take place during the summer
  and winter months.
  - **Please note** that the best time to plant seeds is spring time (late March-April.) or early autumn (Sept/Oct).
- **Packaging:** 2Kg bag (20m² coverage), 5Kg bag (50m² coverage), 20 Kg bag (200m² coverage)
- **Sowing Rate:** 100g/m² of mix (mix includes blend of selected seeds, bulking aggregate, seed adhesive, organic nutrients & beneficial Mycorrhizal fungi
- **Application:** Avoid sowing in strong winds. The substrate is to be watered immediately prior to application of the seed mix. *Sow* approximately 50% of the mix longitudinally down the roof,



and then over-sow at 90° with the remainder of the mix. **Do not rake the seed mix into the substrate surface.** The seed mix needs light to germinate.

- Watering: The substrate is to be watered immediately prior to application of the seed mix. Please note that the seed mix is only to be lightly watered in during the summer or where activation of the adhesive element is required in exposed locations. Please avoid overwatering to prevent seed washout.
- **Post installation watering:** It is essential that the growing medium remains moist following germination for a further 10 weeks until established Refer to 'Establishment Watering' below for further guidance.

# **BIODIVERSITY DESIGN CONSIDERATIONS**

- Biodiversity planting and landscape elements are typically drafted in accordance with an ecologist's report and recommendations.
- Biodiversity roofs can be seeded with Bauder Flora seed mixes or planted, as specified by the client and in accordance with an ecologist's report and recommendation.
- Some of the areas can be left to naturally colonise with indigenous flora and fauna.
- Within the substrate elements, graded shingle can also be incorporated. These areas can be
  designed to provide raised mounds within the broad design and should be of varying height.
  They should constitute at least one fifth of any roof area.
- It is suggested that dead wood elements (e.g. dry logs 100mm x 500mm x 1000mm), be placed onto the substrate to provide an important rotting wood ecological niche for rare invertebrates (supplied by others).
- Weight loadings for any surface landscaping items, such as rocks, logs, undulating areas of growing medium and fully established planting /vegetation, making up the biodiversity landscaping (non-Bauder products), should be provided directly from the relevant supplier and should be the subject to a structural engineer's approval.
- Please note Bauder Ltd does not take any responsibility for the design, performance or maintenance of any planting schemes.

# 820B EDGE RETAINING PROFILE INSTALLATION

- Cutting: Neat, accurate and without spalling.
- **Junctions:** Use the supplied connection pieces to reinforce and support the abutment of trim sections.
- **Corners:** The trim is cut to the length required. The supplied aluminium connection pieces have a perforated vertical line in the centre of the component to enable folding the unit through 90° to form the corner reinforcement.
- Position: True to line and level. Smooth continuous lines.
- **Fixing:** The AL150 Sedum blanket edge trim is to be secured in place using additional strips/sections of capping sheet/membrane/waterproofing system the same as the main field area of the roof.
  - Bitumen Membrane Green Systems Bauder capping sheet cut into strips 500mm x 200mm, these bituminous flashings should be torched through the holes in the trim to the waterproofing surface and set at intervals of 400mm between each flashing piece, bonding onto the main capping sheet by a minimum 100mm.
  - Bauder Single Ply Green Systems Reinforced single ply membrane cut into strips 1000mm x 200mm. These retention flashings should be aligned to the vertical inner face of the trim and then welded into position starting with the holes in the fixing arm, then proceed to complete the full welding of the back edge of the retention flashing and the sides. The retention flashings to be set at intervals of 400mm between each flashing piece, bonding onto the main membrane by a minimum 100mm.
  - Bauder LiquiTEC Roofing System Sections of LiquiDETAIL incorporating 110g



Reinforcement fleece. These are to be a minimum of 1000mm x 200mm, applied through the holes in the trim to the waterproofing surface and set at intervals of 400mm, bonding onto the adjacent waterproofing by a minimum 100mm.

- **Location:** To contain soft landscaping at abutments and open perimeters, used in conjunction with the vegetation barrier.
- **Precautionary note:** When cutting metal, please ensure that appropriate tools and personal protection equipment are used.

#### 825 INSTALLATION OF IRRIGATION PIPEWORK

• Pipe work should be installed and connected in accordance with the irrigation supplier's installation guidelines and set as per the plan provided.

**Bauder Vegetation Blankets** - Pipework should be secured at intervals to the vegetation blanket using wire or cable ties, as required. Over time the planting will cover the pipework, visually hiding it.

Bauder Plug Plants / Bauder UK Native Plug Plants / Flora Seed Mixes / Biodiversity - Pipework should be secured at intervals to the substrate as required using plastic pegs (available from irrigation supplier). Please note pegs should be installed in a manner so as not to cause damage to the waterproofing.

### 830 INSPECTION CHAMBER INSTALLATION

- Location: Install centrally over rainwater outlets.
- Orientation: Align parallel with adjacent features.
- **Surround:** Using 20/40mm grade washed pebbles; the inspection chamber must be surrounded by a 500mm vegetation barrier surround to prevent unwanted growth obstructing the drainage system.
- Positioning: Never place directly on the waterproofing membrane see options below-Intensive / extensive soft landscaping: Placed directly on to the drainage / water storage layer.

**Inverted roof with pebble ballast:** Placed directly on the vapour permeable membrane or filter layer.

**Decorative aggregate finishes:** Placed directly on the protection layer or vapour permeable membrane / filter layer

**Important Note:** Ensure that a suitably sized hole has been cut out of the underlying drainage board / protection layer to allow water to flow freely into the outlet.

- Chamber Height: The contractor should also allow for the installation of additional Bauder height adapter units as required, in order to bring the inspection chamber up to at least the height of the surrounding landscaping. These are available in either 50mm or 100mm units.
- Box gutters and gullies: Where a box gutter is to be constructed, provision should be made to accommodate the 250mm diameter of the inspection chamber. The front support leg of the chamber will need to be removed (see installation guide) for the unit to fit inside a box gutter /gully. We recommend that all box gutters are constructed to a minimum finished width of 500mm to ensure that the support feet of the inspection chamber sufficiently clears the angle fillets within the gutter sole and leaves space to dress the pebble vegetation barrier around the main body of the chamber.
- **Precautionary note:** When cutting metal, please ensure that appropriate tools and personal protection equipment are used.

# 830A RAINWATER OUTLET ACCESS COVER (FOR PAVED LANDSCAPING AREAS)

• The contractor shall provide a suitably sized Bauder rainwater access inspection cover over all internal rainwater outlets.



• Required where traditional paving slabs on pedestal supports are specified, for maintenance access.

• **Completion:** The feet of the unit should be manually adjusted so it finishes flush with the surrounding paved surface.

### 830C LINEAR DRAINAGE SYSTEM

- **Drainage channels:** Bauder KH60 linear drainage channel, 1.5mm galvanised steel channel sections, 1000 x 150 x 60mm with integral grille plate.
- Connecting the drainage channels: Individual sections of Bauder KH60 channel should be joined using Bauder Connection Clips, with Bauder Stop Ends used where the drain terminates at abutments.
- Installation:

On Gravel Support Bedding: The channel is to be fully supported on free draining crushed aggregate i.e. Bauder mineral drain. For levelling purposes, the Bauder KH60 channel sections are to be laid on a 30mm deep 2-5mm crushed granular bedding layer and levelled as required finish flush with adjacent paving. Please note that the crushed aggregate materials below the linear drainage channels will have to be contained to prevent loss beneath the related drainage board product - either contained with Bauder filter fleece or retained using a perforated non-corroding metal support angle.

On Adjustable Legs: Leg sets are available allowing the linear drain channel height to be adjusted between 75-120mm. Please note that leg sets must be ordered separately.

- These drainage channel units are perforated and designed to allow water to discharge at a controlled rate into the drainage layer below.
- Please note that these units are not suitable for supporting the weight of vehicular traffic.

## 830F PURPOSE FABRICATED PARAPET EMERGENCY OVERFLOW GRAVEL GUARD

- Location: Install/place centrally over Bauder Parapet Emergency Overflow opening. The bottom edge of the gravel guard is to sit on the Bauder Protection Layer.
- **Width:** Bauder recommends a width of 200mm to ensure full coverage of the Bauder Parapet Emergency Overflow opening.
- Backfill: 20/40mm washed pebbles
- **Installation:** Provision should be made by the contractor to supply a 'pre-bent' perforated stainless steel gravel guard, placed centrally to all Bauder Parapet Emergency Overflow openings. The plate should cover the whole of the opening and be constructed / designed to ensure that no growing medium or vegetation barriers pebble can pass through once installed. Bauder should be contacted if there are any queries relating to this item.

#### 832A BEDDING LAYER

- Extent: To designated areas beneath permeable paving See landscape designer's plan.
- **Installation:** Apply evenly over to provide a level finish. Depth to be a minimum of 30mm, but not exceeding 50mm. Provision should be made for containing the bedding layer at all abutments to ensure that loose gravel particles do not drop into the area beneath the drainage layer, where they may wash into the outlets i.e. use perforated aluminium retention angles or abutment kerbs.
- **Perimeter edge and abutment restraint:** It is important that provision is made to support and retain the mineral drain fill and aggregate bedding layer within the construction at abutments, by adopting one or both of the following methods (dependent upon the nature of the construction)...
  - 1. Concrete kerb bedded in concrete off of the drainage board layer, or perforated stainless steel or aluminium angle bolted together and inserted below the drainage layer.



2. Angles made from aluminium should be 1.5 –2.5mm or stainless steel 1 - 1.5mm thickness should be used. The opposite side of the angle should be supported by a 20/40mm pebble vegetation barrier of approximately the same depth as the landscape construction.

### 835 ADJUSTABLE PEDESTAL SUPPORTS

- Product ref: Bauder Pedestal Support System
- Material: Polypropylene copolymer with min. 65% recycled content.
- Colour: Black
- Placement Supports to be installed according to the Bauder System build-up below:
  - o Bituminous membranes: directly on to the waterproofing (inc. Bakor hot melt).
  - Inverted insulation: directly on to filter layer/vapour permeable membrane/root resistant geotextile membrane (where applicable),
  - o Thermofol Single Ply Membrane: directly on to membrane surface.
  - o **Thermoplan Single Ply membrane:** directly on to membrane surface.
  - o **LiquiTEC liquid cold applied system:** directly on to heavy duty wearing course.
- Range of adjustment: 17mm 850mm (bracing system used on heights over 600mm).
- Head support (surface area): 190cm<sup>2</sup>.
- Base Support (surface area): 315cm<sup>2</sup>.
- Spacers/ shims: range available.
- Spacer tabs: Available to provide drainage gaps2mm, 4.5mm, 6mm, 8mm and 10mm.
- **Slope compensation:** 0% 5% at half degree increments.
- Compressive strength: Maximum 1000Kg.
- Installation: Please refer to the manufacturer's technical literature and guidelines.
- **Extenders:** Additional height adjustment, where required, can be obtained by using extenders. See information above and the technical literature.
- Installation: System to be installed in accordance with the technical literature and installation instructions. If there is any doubt as to the exact requirements consultation should be made with Bauder Limited.

## 840 VEGETATION BARRIER / DRAINAGE BARRIER

- A vegetation barrier must be provided to all perimeters, abutments penetrations including protrusions i.e. man-safe posts etc. We recommend 20/40mm rounded river washed pebbles. Stones/ aggregates with sharp edges must not be used i.e. flint.
  - In accordance with current GRO guidelines, the specified barrier widths are as follows: -
- Minimum 300mm, but increasing to 500mm at vertical walls with opening windows or doors or to abutments with opening rooflights.
- Every 40m, there is a 30mm high barrier constructed of non-flammable materials or a one metre wide strip of solid paving, gravel or pebbles.
- At all open drainage perimeters, drainage trim must be used to contain the vegetation barrier.
- For extensive green/blue roofs where Bauder XF301 Sedum Blanket is specified, the vegetation barrier must cover the edges of the blanket by a minimum of 100mm in order to protect the exposed edge of the blanket against wind uplift and substrate erosion. Please refer to Bauder standard green roof detailing for other extensive green roof systems.
- Vegetation barriers removal or reduction of the recommended width: Pebble vegetation
  barriers function as a fire break between potentially flammable dry vegetation and abutting
  construction materials that are also potentially flammable, to prevent fire spreading. These can
  be seen as an aesthetic issue for smaller green/blue roof areas and for this reason some
  clients/designers choose to reduce this width or otherwise remove the barrier altogether.
  The current barrier guidelines are set by the GRO codes of practice that Bauder follows and

The current barrier guidelines are set by the GRO codes of practice that Bauder follows and promotes. These are guidelines and not currently a legal requirement under British Standards



or Building Regulations. However, not following these guidelines may affect an insurance claim in the unlikely event of a fire. Consequently, Bauder Ltd cannot accept liability for issues arising from non-compliance with the current GRO guidelines.

### 841A LAYING PRECAST PAVING SLABS

- **Extent:** To designated areas See landscape designers plan.
- **Support:** Slabs to be laid on the specified proprietary support pads, adjusted in accordance with the manufacturer's recommendations to ensure a flush, level finished surface.
- **Setting out:** Minimize cutting.
- **Joints:** 4.5mm.
- Completion: Slabs must be level and stable.

## 841B LAYING PRECAST PAVING SLABS

- Extent: To designated areas See landscape designers plan.
- **Paving installation:** Slabs to be laid on to the specified bedding layer, installed as specified by the architect / landscape designer and strictly in accordance with their specific recommendations regarding the layout in keeping with the landscape design.
- Setting out: Minimize cutting.
- **Joints:** Left open for drainage. The size of the joints to be in accordance with the clients requirements. These open joints may be controlled by using either proprietary spacers or using suitable strips of cut tile of the correct thickness or similar, to control the gap size.
  - Width: 8mm.
  - Perimeter upstands: 8mm.
- Completion: Slabs must be level and stable.

#### COMPLETION

### 910 INSPECTION

- **Timing:** Before handover.
- Give notice (minimum): 3 days.

## 915D ESTABLISHMENT WATERING REQUIREMENTS

- The substrate will have been watered prior to application of the seed mix. Please note that the seed mix should only then be lightly watered in during the summer or where activation of the adhesive element is required in exposed locations. Please avoid over-watering to prevent seed washout.
- Once the seeds have germinated, it is essential that the growing medium is kept moist for a further 10 week period until planting is established. It is the responsibility of the roofing contractor to liaise with the main contractor/ building owner to provide water and ensure that the necessary watering programme (as indicated above) is instigated following installation.
- An adequate mains water supply of sufficient pressure must be available and operational prior to the plants being delivered and installed. Initial watering must be by surface mounted sprinklers.
- Refer to the Bauder Watering Guide document for further information on watering.
- Bauder Ltd accepts no responsibility whatsoever for the condition of installed planting that is not properly watered or irrigated following landscaping works.

# 916 POST INSTALLATION MAINTENANCE

• The installing contractor should price into the tender, the cost of carrying out post-installation maintenance for a contract period to be agreed with the client's representative. Following



completion of the landscaping installation and handover, the responsibility for future on-going maintenance of the green/blue roof planting becomes the responsibility of the building owner or the Main Contractor, where this element forms part of the contract.

- Blue Roof Outlet Maintenance: It is important that the Bauder Bitumen Blue Roof Vertical
  Outlets and Bauder Blue Roof Flow Restrictors are checked and maintained regularly to
  ensure there are no blockages that will affect the calculated flow rate. In addition to regular
  maintenance inspections the outlets should be inspected after a storm event.
- Maintenance services: Bauder Ltd offers a professional maintenance service using experienced green/blue roof technicians and would be pleased to provide an estimate for carrying out on-going maintenance. Please contact our green roof maintenance team on Tel: 01473 257671. Alternatively, the work can be contracted to experienced landscape contractors of your choice.
- Period of maintenance contract: Insert requirement i.e. one year, two years etc.
- Scope of maintenance procedure: as per manufacturer's recommendations.

# 920 COMPLETION

- **General:** Leave the works in a clean, tidy condition.
- Surfaces: Clean immediately before handover.
- Outlets: Clean and clear of obstructions.
- Completed green/blue roof: Protect from adjacent or high-level working.

## 930 DOCUMENTATION

- Timing: Submit at handover.
- Contents:
- Manufacturer's guarantees and warranties.
- Procedures for maintenance of the green/blue roof.
- Record drawings showing the location of planting and associated features.
- Number of copies: as required by client.

Bauder reserves the right to amend information and product specifications without prior notice. All reasonable care has been taken to ensure that the information is current and correct at the time of issue. Please note that any future regulation changes could result in this specification requiring an update. The specifier is responsible for ensuring that this specification information is still current prior to issue, as Bauder Ltd can accept no liability for any resulting errors or omissions.