

Camden Planning Guidance

Amenity

London Borough of Camden

CPG 6



CPG6 Amenity

1	Introduction	5
2	Air quality	7
3	Contaminated land	15
4	Noise and vibration	19
5	Artificial light	25
6	Daylight and sunlight	31
7	Overlooking, privacy and outlook	37
8	Construction management plans	39
9	Access for all	45
10	Wind and micro-climate	53
11	Open space, outdoor sport and recreation facilities	59
12	Planning for healthy communities	79

1 Introduction

What is Camden Planning Guidance?

- 1.1 We have prepared this guidance to support the policies in our Local Development Framework (LDF). It is therefore consistent with the Camden Core Strategy and Development Policies, and is a formal Supplementary Planning Document (SPD) which is an additional “material consideration” in planning decisions. This guidance will replace Camden Planning Guidance 2006, updating advice where appropriate and providing new guidance on matters introduced or strengthened in the LDF.
- 1.2 Camden Planning Guidance covers a range of topics (such as design, housing, sustainability and planning obligations) and all of sections should be read in conjunction with, and within the context of, Camden’s other LDF documents.

Amenity in Camden

- 1.3 A key objective of the Camden Core Strategy is to sustainably manage growth so that it avoids harmful effects on the amenity of existing and future occupiers and to nearby properties.

What does this guidance cover?

- 1.4 This guidance provides information on all types of amenity issues within the borough and includes the following sections:
 1. Air quality
 2. Contaminated land
 3. Noise and vibration
 4. Artificial light
 5. Daylight and sunlight
 6. Overlooking, privacy and outlook
 7. Construction management plans
 8. Access for all
 9. Wind and micro-climate
 10. Open space, outdoor sport and recreation facilities
- 1.5 This guidance supports the following Local Development Framework policies:

Camden Core Strategy

- CS5 - Managing the impact of growth and development
- CS15 - Protecting and improving our parks and open spaces & encouraging biodiversity
- CS16 - Improving Camden’s health and well-being

Camden Development Policies

- DP26 - Managing the impact of development on occupiers and neighbours
- DP28 - Noise and vibration
- DP31 - Provision of, and improvements to, public open space and outdoor sport and recreation facilities
- DP32 - Air quality and Camden's Clear Zones

2 Air quality

KEY MESSAGES:

- All of Camden is a designated Air Quality Management Area due to the high concentrations of nitrogen dioxide (NO₂) and particulate matter (PM₁₀).
- All developments are to limit their impact on local air quality.

2.1 Poor air quality can harm health and the environment. The Council aims to make sure that new development does not harm air quality. This guidance provides advice on how to address air quality issues in planning applications.

2.2 Camden Core Strategy policy CS16 - *Improving Camden's health and well-being* and policy DP32 – *Air quality and Camden's Clear Zone* of the Camden Development Policies sets out our approach to air quality in the borough.

2.3 *Planning Policy Statement PPS23: Planning and Pollution Control* contains the Government's core policies and principles on air quality and air pollution. The London Plan outlines regional policies related to protecting local air quality during the planning process.



Air quality in Camden

2.4 An Air Quality Management Area (AQMA) must be declared by the local authority for an area that is unlikely to meet the national air quality targets for specific air pollutants. The authority then produces a Local Air Quality Action Plan. See Camden's website for our air quality plan.

2.5 The whole of Camden is an Air Quality Management Area (AQMA) as it does not meet national air quality targets for nitrogen dioxide (NO₂) and particulate matter (PM₁₀). The main sources of air pollution in Camden are road transport and gas boilers. The Council's Air Quality Action Plan outlines measures to reduce emissions from the key sources of air pollution in the borough. Included in the plan are measures to minimise and control NO_x and PM₁₀ emissions associated with new developments both during the construction of a building and its future use.

2.6 Air quality is particularly poor in the south of borough which is characterised by high levels of traffic. We will only grant planning permission for development that significantly increases travel demand in

the south of the borough where it includes appropriate measures to minimise the transport impact of development.

- 2.7 Where appropriate we will seek developments to include monitoring equipment to allow us to better understand local air quality.

WHAT DOES THE COUNCIL REQUIRE?

The Council's overarching aim is for new development is to be 'air quality neutral' and not lead to further deterioration of existing poor air quality.

You will be required to include mitigation and offsetting measures to deal with any negative air quality impacts associated with your development proposals. At the same time your development should be designed to minimise exposure of occupants to existing poor air quality.

To manage and prevent further deterioration of air quality in Camden, we will require an air quality assessment with planning applications for development that could have a significant negative impact in air quality. This impact can arise during both the construction and operational stages of a development as a result of increased NO_x and PM₁₀ emissions.

- 2.8 An air quality assessment will also be required for a proposal if it introduces uses that are susceptible to poor air quality, such as housing or a school, into areas of particularly poor air quality.
- 2.9 The Council will not grant planning permission for developments that could significantly harm air quality or introduce people into areas of elevated pollution concentrations, unless mitigation measures are adopted to reduce the impact to acceptable levels and protect public exposure (see paragraph 32.4 of policy DP32 of the Camden Development Policies).
- 2.10 Although all of Camden is covered by an AQMA we will only require an air quality assessments where development could potentially cause significant harm to air quality as set out in the table below.

An Air Quality Assessment is required in developments:

- with potential to significantly change road traffic on any road exceeding 10,000 vehicles per day. Significant changes include:
 - increase in traffic volumes > 5% (Annual Average Daily Traffic (AADT) – or peak);
 - lower average vehicle speed or significant increase in congestion;
 - significant increase in the percentage of HGVs;
- that introduce, or increase car parking facilities by, 100 spaces or more;
- with commercial floorspace of more than 1,000sq m;
- with more than 75 homes;
- where people will be exposed to poor air quality for significant periods of the day, in particular developments located on busy roads;
- involving the following - biomass boilers, biomass or gas combined heat and power (CHP);
- involving industrial or commercial floorspace regulation under the Environmental Permitting (England and Wales) Regulations (EPR) which will be subject to Environmental Assessment under the Town and Country Planning (Environmental Impact Assessment) Regulations 1999.

What should an air quality assessment cover?

2.11 Air quality assessments for developments potentially contributing to poor air quality are to include the following:

- a) An inventory of the PM₁₀ and NO_x emissions associated with the proposed development, including the type and quantity of emission concentrations, during the construction and operational phase. This shall cover transport, stationary and mobile emission sources.
- b) The application of atmospheric dispersion modelling to predicted existing and future NO₂ and PM₁₀ concentrations, both with and without the proposed development. Dispersion modelling shall be carried out in accordance with Air Quality and Planning Guidance, London Councils (2007) and Technical Guidance Note (TG09). (Specific guidance for modelling combustion plant emissions can be obtained from the Council's Sustainability Team – see Useful Contacts at the end of this section).
- c) An assessment of the significance of air quality impacts during both the construction and operational phases. Reference shall be made to the Environmental Protection UK Guidance Note: Development Control: Planning for Air Quality (2010 Update).
- d) Consideration of the potential cumulative impacts on air quality which may arise during the construction or operational phases as a result of emissions arising from other developments within a 100m radius of the development.
- e) Where a biomass boiler or combined heat and power (CHP)/combined cooling, heating and power (CCHP) will be used for

on site energy generation, you are to complete the Council's Air Quality Information Request Form. This requires specific technical details related to the appliance, fuel type, emission concentrations, maintenance and exhaust stack. The forms can be obtained from Camden's Air Quality Officer or the Council's air quality webpage under Environment.

- f) Applications which include biomass boilers or biomass CHP, the air quality assessment shall compare the impact of emissions from the intended biomass boiler/CHP and a gas boiler/CHP of identical thermal rating.
- g) An indication of the number of new occupiers and users of the site who will be exposed to poor air quality as a result of the development (the occupiers/users should also be shown on a map). For further information please refer to the Environmental Protection UK Guidance Note: Development Control: Planning For Air Quality (2010 Update).
- h) An assessment of the impacts on air quality of the demolition and construction phase and details of mitigation methods for controlling dust and emissions from plant and machinery. Reference should be made to the Best Practice Guidance: The control of dust and emissions at construction and demolition, London Councils (2006).
- i) An outline of, and justification for, mitigation measures associated with the design, location and operation of the development in order to reduce air pollution and exposure to poor air quality.

Developments containing sensitive uses

- 2.12 Developments which will not result in additional NO_x and/or PM₁₀ emissions and present no risk in worsening air quality, but introduce new sensitive uses to an area which breaches the air quality standards for NO₂ or PM₁₀ need to submit an assessment of the local air quality but can omit requirements B, D and E above.

What measures can reduce air pollution emissions and protect public exposure?

- 2.13 Various actions can be taken to mitigate air pollution emissions arising from the construction and operational phases of a new development. Additional actions can be adopted to curtail public exposure in areas where air pollution levels are particularly high. These should be taken into account during the design stage of an application. The key measures are detailed below:

Demolition and construction

- 2.14 The impact of the construction and demolition phases of a development on air quality must be taken into account as part of your planning application. Exhaust



emissions from construction vehicles and machinery such as generators, piling and grinding equipment can result in:

- dust emissions;
- gases (NO_x); and
- fine particles.

2.15 Controlling dust emissions is important to:

- prevent disturbance to local residents due to soiling;
- minimise damage to vegetation; and
- reduce impacts on local PM₁₀ concentrations, thereby protecting public health.

2.16 We may require PM₁₀ monitoring, before and during the construction and demolition phase, dependant upon the scale of the proposed development.

2.17 We will encourage best practice measures to be adopted during construction and demolition work to reduce and mitigate air pollution emissions. You will be encouraged to adopt the procedures outlined in the London Council's best practice guidance *The control of dust and emissions from construction and demolition*. These focus around three principles to control emissions – prevention, suppression and containment. We will expect you to include the following items in construction management plans:

- Identification of whether demolition/construction represents a low, medium or high risk site in the context of air quality.
- Identification of the best practice measure required to control and mitigate plant and vehicles exhaust emissions.
(See section 8 of this Guidance on Construction management plans for further details).

Distance of impacts

Depending of the size, location and characteristics of your development, impacts from demolition and construction phases can occur at distance of 10 to 500m.

Building location and design

2.18 The location of a development has a direct influence on exposure to elevated air pollution levels. This is particular relevant where developments include sensitive uses such as hospitals, schools and children's playgrounds. Suitable building design, layout and orientation can avoid increasing exposure whilst minimising energy demand and energy loss. The Council requires the impact of outdoor air pollution on indoor air quality in new developments to be taken into account at the earliest stages of building design.

- 2.19 The location of outside space is also an important consideration and any exposure of gardens and roof terraces should be screened and, where practicable, minimised through appropriate positioning and orientation. You should take care not to locate flues and exhaust vents in close proximity to recreational areas such as roof terraces or gardens. An energy efficient building design can minimise air pollution resulting from the use of gas boilers. Adopting sustainable building design (e.g. the Code for Sustainable Homes and the Building Research Establishment Environmental Assessment Method (BREEAM)), will reduce thermal heat losses and result in less gas use leading to lower NO_x emissions. See Camden Planning Guidance 3 – Sustainability for further details on the Code and BREEAM.

Gas boilers

- 2.20 Gas boilers are a large source of NO_x emissions in Camden. In order to minimise NO_x emissions arising from heating and hot water systems the Council requires boilers fitted in new development to achieve a NO_x emissions of <40 mg/m³ and an energy efficiency rating >90%.

Renewable Energy and Combined Heat and Power

- 2.21 Core Strategy policy CS13 promotes the use of renewable energy technologies to reduce carbon emissions and tackle climate change. The adoption of renewable energy and energy efficiency technologies in major developments can minimise air pollution emissions through reductions in gas consumption required for heating and hot water. These include solar thermal collectors and ground source heat pumps in addition to gas and hydrogen fuel cell combined heat and power (CHP) or combined cooling heat and power (CCHP).

Hydrogen fuel cell

A fuel cell is an electrochemical cell that converts energy from a fuel (hydrogen) into electricity.

- 2.22 Biomass boilers however can give rise to higher emissions of NO_x and PM₁₀ emissions than conventional gas boilers. Permission to operate these appliances will only be granted if the air quality impacts are demonstrated to be equivalent or lower than those associated with a conventional gas boiler of similar thermal rating. Where an assessment demonstrates adverse effects on air quality, this type of biomass boiler should not be used in the development.
- 2.23 You are advised to refer to the national guidance note *Biomass and Air Quality Guidance Note for Local Authorities*, published by Environmental Protection UK. In cases where emissions released from a biomass boiler do not lead to negative impacts on air quality, the



appliance will be required to meet high standards of air pollution control with particular emphasis given to:

- boiler design and operation;
- pollution abatement equipment;
- servicing and maintenance;
- fuel quality, storage and delivery; and
- exhaust stack height.

2.24 We will require evidence that the exhaust stack height of gas CHP/CCHP has been appropriately calculated to guarantee that NO_x emissions are effectively dispersed, and do not risk increasing ground level NO₂ concentrations. An air quality assessment will be required for developments including CHP/CCHP. Where the assessment reveals a negative impact on air quality, mitigation measures will be required entailing the best available techniques to reduce emissions. This includes the installation of NO_x abatement technology such as:

- use of low NO_x burners; or
- increasing stack height.

2.25 A programme of on-going maintenance and servicing will be necessary to minimise gas emissions released from CHP/CCHP.

2.26 The Council will use Section 106 obligations to set requirements for controlling emissions from biomass boilers and CHP/CCHP.

Traffic Reduction

2.27 Reducing car usage caused by new developments is the principle way to minimise vehicle emissions and protect local air quality. Please refer to transport policy *CS11 - Promoting sustainable and efficient travel* in the Camden Core Strategy for more on our approach to improving air quality through transport measures. This requires:

- the adoption of car free and car capped developments;
- provision cycling facilities to encourage sustainable transport;
- green travel plans;
- provision of car club bays; and
- infrastructure for low emissions vehicles such as electric vehicle recharging points.

Further information

Planning Guidance	<ul style="list-style-type: none"> • Planning Policy Statement 23: Planning and Pollution Control (2004) • Planning Policy Statement 23 Annex 1: Pollution Control, Air and Water Quality <p>These documents outline the government's advice on methods of planning for pollution control.</p>
Air Quality Guidance	<ul style="list-style-type: none"> • Technical Guidance Note: Assessment of Air Quality Issues of Planning Applications, Association of London Government (ALG), 2006 This provides technical advice on how to deal with planning applications that could have an impact on air quality. • Development Control: Planning for Air Quality. Environmental Protection UK, 2010 This advises of the significance of air quality assessments within the planning process. • Best Practice Guidance - The control of dust and emissions from construction and demolition (London Councils) 2006 The aim of this guidance is to protect the health of on-site workers and the public and to provide London-wide consistency for developers. • Biomass and Air Quality Guidance for Local Authorities (Environmental Protection UK) 2009 This guidance details procedures for assessing and managing the effects of biomass on air quality and provides background material. • Low Emission Strategies (Beacon Low Emission Group) 2009 This provides advice on how to reduce emissions of air pollutants and greenhouse gases from transport.
Useful Contacts	<p>Camden Council Corporate Sustainability Team www.camden.gov.uk/smallsteps (020 7974 4444) provides guidance on air quality in Camden</p>

4 Noise and vibration

KEY MESSAGES:

We will ensure that noise and vibration is controlled and managed to:

- Limit the impact of existing noise and vibration sources on new development; and
- Limit noise and vibration emissions from new development.

- 4.1 The impact of noise and vibration can have a major affect on amenity and health and can severely affect people's quality of life.
- 4.2 Policy *DP28 – Noise and Vibration* of the Camden Development Policies aims to ensure that noise and vibration is controlled and managed. It sets out the Council's thresholds for noise and vibration and goes beyond the thresholds set out in Planning Policy Guidance 24: Planning and noise (see below). DP28 contains noise/vibration thresholds for the day, evening and night.



How can the impact of noise and vibration be minimised?

- 4.3 The main sources of noise and vibration in Camden are generated from:
- Road traffic;
 - Railways;
 - Industrial uses;
 - Plant and mechanical equipment;
 - Entertainment uses (such as bars and nightclubs); and
 - Building sites.
- 4.4 For details on how to manage noise and vibration from building sites see section 8 on Construction management plans.

Ways to minimise the impact of noise on your development

Design

- Locating noise sensitive areas/rooms away from the parts of the site most exposed to noises;
- Creating set backs;
- Designing the building so its shape and orientation reflect noise and protect the most sensitive uses;
- Stacking similar rooms (such as kitchens and living rooms) above each other; and
- Positioning non-residential uses closer to the noise source in mixed use developments.

Built fabric

- Insulating and soundproofing doors, walls, windows, floors and ceilings;
- Sealing air gaps around windows;
- Double glazing;
- Including architectural fins (where appropriate); and
- Laminated glass.

Landscaping and amenity areas

- Incorporating planting, landscaping, fencing/barriers and solid balconies to reflect sound.

- 4.5 Our preference for controlling noise:
- Begins with attempting to reduce noise at its source;
 - Then to separate the development (or at least the sensitive parts e.g. habitable rooms) from the source or to use noise barriers; and

- Finally construction materials such as acoustic glazing should be used.

- 4.6 When you consider measures to minimise noise and vibration you also need to take into account our policies on design and crime prevention. You should consider the implications of noise and vibration at the beginning of the design process to enable prevention or mitigation measures to be designed into the scheme. Poorly designed schemes will not be acceptable.
- 4.7 Proposals will be expected to include appropriate attenuation to alleviate or mitigate the impact of noise and vibrations to an acceptable level, as set out in policy *DP28 – Noise and vibration* of the Camden Development Policies. Where appropriate, the Council will consider the cumulative impact of noise sources (for example, air conditioning units).
- 4.8 Everyday domestic activities can also generate noise, e.g. communal entrances and roof terraces. Sufficient sound insulation must be provided between dwellings to prevent the transmission of noise between them, particularly in conversions where new partition walls are often deficient in terms of insulation.

Ways to mitigate noise emitted by your development

Engineering

- Reducing the noise emitted at its point of generation (e.g. by using quiet machines and/or quiet methods of working);
- Containing the noise generating equipment (e.g. by insulating buildings which house machinery and/or providing purpose-built barriers around the site); and
- Protecting any surrounding noise-sensitive buildings (e.g. by improving sound insulation in these buildings and/or screening them by purpose-built barriers).

Layout

- Ensuring an adequate distance between source and noise-sensitive buildings or areas; and
- Screening by natural barriers, buildings, or non-critical rooms in the development.

Administrative

- Limiting the operating time of the source;
- Restricting activities allowed on the site; and
- Specifying an acceptable noise limit.

- 4.9 If your proposal could result in noise and vibration that would cause an unacceptable impact to nearby uses or occupiers, or proposes sensitive uses near a source of noise or vibration and cannot be adequately attenuated then planning permission is likely to be refused.

Developments will be assessed against the thresholds set out in policy DP28.

How will the Council manage the impact of noise and vibration?

- 4.10 Detailed acoustic/noise and vibration information in the form of a report will be required if your development proposes:
- The installation of plant, ventilation or air conditioning equipment;
 - A use that will create significant noise (e.g. new industry, nightclub)
 - A noise-sensitive development in an area where existing noise sources are present (e.g. an existing industrial site, busy road, railway line);
 - A use that will generate a significant amount of traffic.

Noise sensitive developments

Those developments located near sources of noise, including housing, schools and hospitals as well as offices, workshops and open spaces.

- 4.11 The list above is a guide only and you may need to provide noise and vibration information for other developments depending on the circumstances of the site or proposal.
- 4.12 The appropriate amount and detail of information required will depend on the specific circumstances of your proposal. At a minimum you will be expected to provide the following information to support your application:
- Description of the proposal;
 - Description of the site and surroundings, a site map showing noise and vibration sources, measurement locations and noise receivers;
 - Background noise levels;
 - Details of instruments and methodology used for noise measurements (including reasons for settings and descriptors used, calibration details);
 - Details of the plant or other source of noise and vibration both on plan and elevations and manufacturers specifications;
 - Noise or vibration output from proposed plant or other source of noise and vibration, including:
 - Noise or vibration levels;
 - Frequency of the output;
 - Length of time of the output;
 - Features of the noise or vibration e.g. impulses, distinguishable continuous tone, irregular bursts;
 - Manufacturers' specification of the plant, supporting structure, fixtures and finishes;

- Location of neighbouring windows (and use if applicable);
- Details of measures to mitigate noise or fume emissions and vibration;
- Details of any associated work including acoustic enclosures and/or screening;
- Cumulative noise levels of all the proposed and existing units;
- Hours/days of operation.

4.13 Where appropriate the Council will seek a legal agreement to control or reduce noise levels where this is unlikely to be met through the use of a condition attached to a planning permission.

Further information

PPG24	Planning Policy Guidance Note 24: Planning and Noise provide Government guidance on noise. This guidance defines four Noise Exposure Categories (A-D) and outlines what should be done if your proposal falls into one of these categories. Advice is also provided on how to address noise issues and secure amelioration methods through the planning system. www.communities.gov.uk/publications/planningandbuilding/ppg24
DEFRA	The Department of Food, Environment and Rural Affairs provide a number of publications on noise and noise related issues. www.defra.gov.uk
Camden Council website	Camden's Environmental Health web pages provide strategic information on noise in Camden including the results of monitoring that has taken place www.camden.gov.uk/noise Also see <i>Camden's Guide for Contractors working in Camden</i> on the Camden website.
The Mayor's Ambient Noise Strategy	This provides details on the Mayor of London's approach to reducing noise in London. http://legacy.london.gov.uk/mayor/strategies/noise/docs/noise_strategy_all.pdf

5 Artificial light

KEY MESSAGES:

When considering proposals for artificial lighting the Council will consider the:

- need for planning permission;
- need for the lighting;
- design of the lighting; and
- impacts on biodiversity.

5.1 This section provides guidance on the Council's approach to artificial lighting. This guidance should be read in conjunction with policy *DP26 Managing the impact of development on occupiers and neighbours* of the Camden Development Policies.

5.2 Artificial lighting has many benefits, however excessive or poorly designed lighting can be damaging to the environment and result in visual nuisance including by:

- Having a detrimental impact on the quality of life of neighbouring residents;
- Significantly changing the character of the locality;
- Altering wildlife and ecological patterns; and
- Wasting energy.



5.3 Nuisance often occurs due to glare and 'light spillage' because the lighting has been poorly designed.

5.4 *Planning Policy Statement 23 (PPS23): Planning and Pollution Control* enables the Council to take account of the possible obtrusive impact of

lighting and paragraph 3.25 of PPS23 permits us to use conditions or planning obligations to protect the environment.

WHAT IS LIGHT POLLUTION?

Light pollution is the term used to describe any adverse effect of artificial lighting. Light pollution includes:

- Glare - the uncomfortable brightness of a light source when viewed against a dark sky;
- 'Light trespass' – the spread of light spillage the boundary of the property on which a light is located; and
- 'Sky glow' - the orange glow we see around urban areas caused by a scattering of artificial light by dust particles and water droplets in the sky.

Will planning permission be required for lighting?

- 5.5 Structures supporting, and the installation of lighting equipment may require planning permission, especially if they are substantial or affect the external appearance of a building. Planning permission is not required for the carrying out of maintenance which affects only the interior of the building or does not materially affect the external appearance of the building. Temporary lighting schemes generally do not require planning permission.
- 5.6 Planning permission is normally required for:
- the erection of columns to support lighting or other similar structures;
 - the erection of substantial structures or installations that affect the external appearance of a property;
 - external lighting as part of an industrial or commercial scheme;
 - new lighting structures or works which are integral to other development requiring planning permission; and
 - illuminated advertisements, although there are some exceptions such as those indicating medical services and some commercial advertisements on the front of business premises (See Camden Planning Guidance 1 - Design).
- 5.7 You are advised to check with the Planning Service before installing any lighting scheme. You will need to provide the following details:
- Number of lights;
 - Likely lux output;
 - The height of the lighting columns (if applicable); and
 - The area to be lit.

In accordance with policy DP26 in Camden Development Policies, schemes that would cause harm to amenity will not be permitted.

What information should accompany a planning application?

- 5.8 Where planning permission for lighting schemes is required you will need to submit the information required by paragraph 5.7. We will also expect the submission of the following additional information:
- The design of lights and infrastructure;
 - A plan or plans showing layout of the lights, including orientation of the beams of light;
 - Lighting levels, lumen details, lamp type, wattage;
 - Control systems including types and location of sensors, times lighting will be on; and
 - The need for the lighting, that is, an explanation of what activity the lighting is supporting.

- 5.9 All light installations must be energy efficient and 'Dark Sky' compliant, thereby not causing obtrusive light pollution, glare or spillage (by reference to the British Astronomical Association Campaign for Dark Skies).

Lumen

This is a measurement of the light output from a light source.

Lux

This is a measurement of the light intensity falling on a surface.

Dark sky compliance

To design lighting schemes in order to avoid lighting that extends beyond its intended target and would be inefficient and waste energy. It also avoids glare and light in unwanted areas.

What should you consider when designing lighting?

General lighting requirements

- 5.10 To minimise obtrusive light you should follow the general principles taken from the Institution of Lighting Engineers, Guidance Notes for the Reduction of Obtrusive Light (2005):
- Lighting is to be directed downwards wherever possible to illuminate its target. If there is no alternative to up lighting, then the use of shields will help reduce the spill of light to a minimum. Up lighting is a particularly bad form of obtrusive light and contributes to sky glow.
 - Lighting is to be designed to minimise the spread of light near to, or above, the horizontal. Again, any light that shines above the horizontal line of the light adds to the sky glow effect.
 - Lighting should be designed to the correct standard for the task. Over-lighting is a cause of obtrusive light and also represents a waste of money and energy.
 - The main beam angle of all lights proposed directed towards any potential observer is to be kept below 70°. It should be noted that the higher the mounting height, the lower the main beam angle could be. This will help reduce the effect of glare and light spill on neighbouring dwellings, passing motorists, pedestrians, etc.
 - Lighting should be directed to minimise and preferably avoid light spillage onto neighbouring properties. Wherever possible use floodlights with asymmetric beams that permit the front glazing to be kept at, or near parallel to, the surface being lit.
 - The lights used should be the most efficient taking into account cost, energy use, and the purpose of the lighting scheme required. All lighting schemes should meet British Standards.
- 5.11 We will seek to ensure that artificial lighting is sited in the most appropriate locations to cause minimal disturbance to occupiers and wildlife, while still illuminating the intended area. This includes considering any occupiers located above the lighting source.

- 5.12 Consideration should be given to lighting associated with buildings of special historic and architectural interest in order to protect their special interest and that of the wider area. This applies both to the lighting of such buildings and the impact of the lighting installation when seen by day.

Lighting Infrastructure

- 5.13 The visual effect of lighting infrastructure when viewed in the daytime needs to be considered. These elements can include junction boxes, poles, brackets and cabling. The design, size and colours of the physical infrastructure needs to be carefully considered and should relate to the building it is located on.

Use

- 5.14 The design of lighting should be specific to the use it supports (e.g. for recreation facilities). Hours of lighting should be limited to the times needed to support the use (both in summer and winter) and be restricted through the use of timers and sensors where relevant (e.g. for security lighting).
- 5.15 The Council may seek to secure conditions to any planning permission in order to control the hours of operation of any approved lighting scheme.

Why do impacts on biodiversity need to be considered?

- 5.16 Artificial lighting can often impact on wildlife habitats, particularly where lighting is proposed in open spaces, for example to provide lighting for sports courts and pitches or to improve security (such as along Regents Canal). Artificial lighting can have particularly severe implications for the natural daily rhythms of a range of animals and plants, and therefore sites and habitats identified for their nature conservation value should not be adversely affected by lighting. (See the Local Development Framework Proposals Map for a list of nature conservation sites).
- 5.17 If your proposed lighting is located within or adjacent to areas of open space we will expect that any biodiversity impacts arising from the installation or operation of the lighting is mitigated. This may require a survey to identify if there are any nesting birds in the immediate vicinity or if it is close to an area where bats may hibernate or emerge at feeding time. This is particularly important if the operation of the lighting extends beyond dusk, which is roughly the time bats will come out to forage. See Camden Planning Guidance 3 – Sustainability for further information on our approach to protecting biodiversity.
- 5.18 You should contact Camden's Biodiversity Officer at an early stage to discuss measures to mitigate the impact of lighting schemes on biodiversity.

Further information

PPS23	Planning Policy Statement 23: Planning and Pollution Control. Office of the Deputy Prime Minister, November 2004. www.odpm.gov.uk
DEFRA	The Department of Food, Environment and Rural Affairs has published a number of documents on light pollution. These can be found at: http://www.defra.gov.uk/environment
Environment Act 1995	Available at the Stationary Office: www.opsi.gov.uk/acts/acts1995/Ukpga_19950025_en_1.htm

Useful Contacts

Camden Planning Service www.camden.gov.uk/planning

The Institution of Lighting Professionals www.theilp.org.uk promotes good practice and excellence in lighting schemes.

The Chartered Institute of Building Services Engineers www.cibse.org provides information on appropriate lighting designs and mechanisms.

Camden Planning Guidance

Transport

London Borough of Camden

CPG 7



CPG7 Transport


1	Introduction	5
2	Assessing transport capacity	7
3	Travel plans.....	13
4	Delivery and servicing management plans	21
5	Car free and car capped development.....	25
6	On-site car parking.....	29
7	Vehicle access	35
8	Streets and public spaces	41
9	Cycling facilities.....	47
10	Minicab offices	56

Camden Planning Guidance

Transport

London Borough of Camden

CPG 7



4 Delivery and servicing management plans

KEY MESSAGES

- Transport Assessments represent the best tool to consider how a development can most appropriately be serviced
- Developments should accord with the Servicing Guidelines provided in this guidance

- 4.1 The purpose of this guidance is to give details on how Delivery and Servicing Management Plans can be used to manage and mitigate the potential impacts of deliveries and servicing on the amenity of occupiers and neighbours.
- 4.2 This guidance relates to Core Strategy Policy CS5 - *Managing the impact of growth and development* and policies DP20 - *Movement of goods and materials*, and DP26 - *Managing the impact of development on occupiers and neighbours* of the Camden Development Policies

When does this guidance apply?

- 4.3 This guidance applies to all development proposals which are likely to generate delivery and servicing movement and therefore may incur significant noise and disturbance impacts. Further details on the circumstances in which the Council will expect/require Delivery and Servicing Management Plans are set out within this guidance.

How should Delivery and Servicing Management Plans be prepared?

Service vehicles and waste collection

- 4.4 General guidance on requirements for service vehicles and goods vehicles is given in Development Policy DP20 - *Movement of goods and materials*. Transport Assessments represent the best tool to consider how a development can most appropriately be serviced. Loading and unloading for some developments can safely and appropriately take place on-street, depending on the nature of the street and the development. Where a development is most appropriately serviced off-street, the application should show that the development will accord with the servicing guidelines shown in the table at the end of this section.
- 4.5 Guideline thresholds for the scale of development where a Transport Assessment will be required are given in LDF Development Policies Appendix 1. For development of significant floorspace in commercial use and residential institutions, the LDF proposes off-site bays for servicing, but also proposes a Transport Assessment that can test the appropriateness of alternative solutions.

- 4.6 For retail-type floorspace (Use Classes A1-A5), the guideline threshold is developments of 1,000 sq m or more. For other commercial floorspace, hotels, and institutional residential accommodation such as hotels, colleges and hostels, the guideline threshold is developments of 2,500 sq m or more. The transport characteristics of Use Classes D1-D2 (including surgeries, places of worship and cinemas) are too variable for any assumption to be made about the need for on-site servicing, but a Transport Assessment is sought in most cases.
- 4.7 The scale of a development is not the only factor controlling the servicing needs it generates. A Transport Assessment is required for any development that would significantly impact the transport system under policy DP16 of the Camden Development Policies. This could be expected to include, for example, any development serviced on-street and likely to receive more than 10 deliveries a day or 2 deliveries an hour. Assessment is also required for developments that generate a number of heavy vehicle movements (see the Assessing Transport Capacity section of this guidance).
- 4.8 If waste collection vehicles need to access a development site, this can be a key consideration in the design of motor vehicle access and circulation spaces. Information on the amount of space needed for sorting and storage of waste on-site prior to collection is given in the Waste recycling and storage section of CPG1 Design. The Council does not generally allow waste to be left on the highway for collection on a specified day except in the case of residential development of 6 dwellings or less.
- 4.9 External storage space for large waste containers is sought for residential development of 7 dwellings or more, and for most non-residential development. The external storage space should be at or near street level, and within 10 metres of a place suitable for a collection vehicle to stop. If appropriate external storage space for waste cannot be provided within 10 metres of the public highway, it will generally be necessary for the collection vehicle to access the development site. In this case, circulation spaces will need to be considered in the same way as those for service vehicles.

Servicing Guidelines

Swept paths	Applicants should provide evidence of swept paths on submitted drawings.
Turning areas	Normally, all vehicles must be able to enter and leave the site in a forward facing direction. If in exceptional cases this is not possible, the service area must be designed to enable vehicles to reverse off the highway rather than onto it.
Demarcation	Servicing bays and turning areas should be clearly marked out, for example, by the use of different colours and materials, to discourage their misuse for car parking and storage.
Pedestrians	Care must be taken to provide safe segregated routes for use by pedestrians. Where access roads for service vehicles represent the most direct or visible route for pedestrians, a segregated footway at least 1.8 m in width should be provided with direct links to each pedestrian entrance of each building on site.
Access roads	A minimum carriageway-width of 6.0 m is required where an internal access is designed for two-way use by service vehicles. Where a footway is not provided to each side, a safety margin with a minimum width of 0.5m must be provided wherever there is no footway.
Headroom	A vertical clearance of 3.5m must be provided for light and medium goods vehicles.

Further information

CPG1 Design, LB Camden 2011

Camden Streetscape Design Manual, LB Camden 2005

Camden Council transport strategies and plans, including the Streetscape Design Manual, can be viewed in the transport and streets section of the Council's website

Residential roads and footpaths: layout considerations - Design bulletin 32 (2nd edition), HMSO 1992 – this can be obtained via:

www.tsoshop.co.uk/bookstore.asp

Camden Planning Guidance

Planning Obligations

London Borough of Camden

CPG 8



CPG8 Planning obligations

1	Introduction	5
2	Background	7
3	Amenity	15
4	Community facilities	21
5	Design	29
6	Affordable housing and housing in mixed-use development..	39
7	Sustainability	45
8	Employment and business support	49
9	Provision of flexible shops and business space	55
10	Transport	56
11	Provision of public open space	59

1 Introduction

What does this guidance cover?

- 1.1 The purpose of this guidance is to provide an indication of what may be required when the Council considers that a development proposal needs a planning obligation to be secured through a legal agreement. Planning obligations can be used positively and to address some of the negative impacts of development which would otherwise make a development unacceptable.
- 1.2 Planning obligations are normally secured under Section 106 (S106) of the Town and Country Planning Act 1990. However, the Government currently intends to introduce a Community Infrastructure Levy (CIL) in order to secure infrastructure funding from individual developments. This is intended to operate alongside the Section 106 system and will be explained further below.
- 1.3 The use of planning obligations is an important tool in ensuring the delivery of necessary infrastructure to support the Local Development Framework. They will be used to ensure that the strategic objectives of the LDF Core Strategy and Development Policies are met through requirements attached to individual development proposals.
- 1.4 The use of planning obligations is specifically required through policy CS19 - *Delivering and monitoring the Core Strategy* although a whole range of individual Development Policies may be used to justify an obligation, particularly those relating to affordable housing, sustainability and transport. This guidance is intended to provide general advice on how planning obligations operate. Large scale developments generally have more significant and complex obligations attached to them, but obligations may also be applied to small scale developments to achieve measures such as car free housing or to manage the impacts of construction.

When will it apply?

- 1.5 This guidance applies to all development where proposals are likely to be subject to planning obligations under Section 106 of the Town and Country Planning Act 1990 (as amended). In dealing with planning applications, local planning authorities consider each proposal on its merits and reach a decision based on whether the application accords with the development plan, unless material considerations indicate otherwise. Where applications do not meet these requirements, they may be refused.
- 1.6 In some instances, however, it may be possible to make acceptable development proposals which might otherwise be unacceptable, through the use of planning conditions (see Department of the Environment Circular 11/95) or, where this is not possible, through planning obligations. Where there is a choice between imposing conditions or entering into a planning obligation a condition will be used.

3 Amenity

- 3.1 Development can be positive, but it can also have a significant environmental impact on the amenity of those who live near the development site. It can sometimes cause general nuisance and disturbance, vibration, noise pollution and dust pollution. Development can also have an impact on the surrounding landscape and biodiversity.
- 3.2 The negative impacts of development on amenity can be and short term and connected to the construction phase of the development, or they can be long term and connected to the day to day operation of the development. The negative impact of a development on the amenity of the surrounding area can normally be offset by good design, planning conditions and controls covered by other legislation.
- 3.3 Where these measures are not adequate to deal with the potential negative environmental impacts of a proposed development which is deemed generally acceptable, a S106 Agreement can be drawn up between the Council and the developer, requiring the developer to undertake certain actions to offset those impacts.
- 3.4 The Council will seek to manage the impact of development when considering a development proposal in line with Development Plan policies DP26 and DP28. However, certain aspects of demolition and construction have specific planning implications and may need to be addressed through planning conditions or planning obligations entered into through a Section 106 Agreement.



Construction

- 3.5 Where demolition and construction is likely to affect local amenity, it is better to consider the environmental impacts at the planning stage and seek ways to minimise them. Many concerns can be addressed through adoption of a co-operative stance between all parties involved and developers should refer to and utilise the Considerate Constructors Scheme.

- 3.6 Many of the environmental impacts of construction works are covered by specific legislation to control pollution, maintain clean air and minimise disturbance. Because of this and other controls small construction projects cause relatively minor amounts of local disturbance and in most cases will not require a section 106 agreement to deal with construction management. However, in the case of large construction and demolition works, planning obligations may be used to minimise the environmental impacts and address the consequences of construction (e.g. to manage construction traffic and/or reinstatement surfaces to a condition that existed prior to construction).
- 3.7 In most cases planning obligations will involve a demolition and/or construction management plan. Please refer to Camden Planning Guidance 6 Amenity, Section 8 for further detail on Construction Management Plans. In these plans the developer undertakes to carry out the demolition or construction works in strict accordance with a plan approved by the Council. The plan may include provisions for phasing, sequential development, management of waste, controlling noise and access during construction. When drawing up the construction or demolition management plan the developer will be required to consult with officers of the Council, the police and local residents and businesses. Local businesses could also be used to supply materials and services in relation to development and construction in order to minimise travel distances and transport costs.
- 3.8 The Council may require the developer to set up a Construction Community Working Group in order to discuss, advise and, where appropriate, make recommendations to the developer in relation to construction management. The Working Group should be made up of an appropriate number of representatives from local residents and/or business associations, a nominee of the Council and/or the Council's Culture and Environment Department, and a project manager and/or Liaison Officer who would act as a point of contact between the local community and the developer.
- 3.9 The Construction Community Working Group can have an input into a Construction or Demolition Plan or Method Statement for Construction, which the developer should submit for the approval of the Council before implementation. The plan or statement should cover the following:
- the programme for construction works;
 - site conditions;
 - erection of hoardings and scaffolding;
 - time of operations;
 - noisy activities;
 - time of deliveries;
 - dealing with construction traffic, vehicles and other likely traffic and parking issues;
 - temporary road and footway closures and surfacing reinstatement/repair proposals; and

- consideration of complaints from the business and residential community.

3.10 Construction should proceed at all times in accordance with this plan or Method Statement.

Construction waste

- 3.11 The Council will seek to minimise the amount of waste generated by a development and to maximise the amount of waste that is reused or recycled. Developers should try to ensure that construction waste is minimised. Recycling of demolition waste can help reduce the amount of aggregates that have to be transported through London and contribute to the saving of resources.
- 3.12 Construction waste needs to be disposed of safely and the vicinity of the construction site should be kept in a clean and safe condition. The Council may require the developer to submit for approval a Construction Waste Management Plan separately, or as part an overall Construction and Demolition Plan, which the Developer will be obliged to follow during the period of construction.

Noise

- 3.13 Noise pollution has a major effect on amenity and on quality of life in general. The Council will not grant permission for noise sensitive development in locations where there is noise pollution, unless appropriate attenuation measures are taken. Policy DP28 *Noise and vibration* sets out the acceptable thresholds for noise in relation to sensitive uses. If suitable separation cannot be achieved the Council will consider whether it is practical to control or reduce noise levels through the use of conditions, planning obligations or other environmental legislation.
- 3.14 Whilst design measures and planning conditions will often be sufficient to address noise impacts within the development site, planning obligations may require financial contributions to fund:
- noise mapping;
 - noise monitoring to identify the number of people adversely affected by noise from road traffic and railways, and to validate noise levels calculated by noise mapping; and/or
 - a post development survey to confirm that requisite measures have been implemented successfully.
- 3.15 In addition the Council may require a noise management plan through a legal agreement, which may require a developer to:
- put in place a scheme for the sound insulation of affected dwellings in order to safeguard amenity;

- reduce noise at source, e.g. by vehicle fleet selection to minimise noise generated by individual vehicles such as delivery lorries, cars and railway vehicles;
- implement off-site noise mitigation measures against traffic noise and vibration such as noise barriers and sound insulation of residential properties and other noise sensitive receivers;
- provide and maintain off-site tree and landscape buffers;
- put into operation a traffic management scheme to reduce road traffic noise; and/or
- work with the local highways authority to implement requisite highways works and a maintenance programme incorporating provision of quieter road surfaces, such as porous asphalt.

Contaminated land

- 3.16 Contamination of the ground and underground water can affect human health, cause harm to the natural environment and damage buildings and underground services. The Council will require measures to remove unacceptable risk from contaminated land and thus make the site suitable for its new use by way of planning conditions.
- 3.17 Where a development includes any potentially contaminative uses the Council will expect proposals to be submitted to prevent future contamination of land or groundwater and may impose planning conditions to that effect. Land contamination issues must be fully addressed in any environmental assessment or statement to accompany a planning application.
- 3.18 For those developments in or adjacent to areas where objectives for land contamination are unlikely to be met by condition (i.e. where there is still a residual impact), the Council will require a S106 planning obligation. The planning obligation will be directed towards measures designed to deal with the contamination, including during construction works, and to make the site suitable for its intended use.
- 3.19 The Council may require a developer to provide a financial contribution for:
- site investigation and remediation works which would include any measures to prevent hazards arising from future use of the site and the disposal or containment of any contaminants;
 - for monitoring following the completion of the development, e.g. measuring gas or water contamination in boreholes or installing permanent monitoring equipment; and/or
 - a post-development survey to confirm that requisite measures have been implemented successfully.
- 3.20 A management plan may also be necessary requiring the maintenance of remedial works such as landscaping or water treatment facilities, or imposing restrictions on the land to minimise and control future potentially hazardous or contaminating development or use of the site.

Microclimate

- 3.21 Large developments have the potential to change the microclimatic conditions in the surrounding area, for example by overshadowing a public space for large parts of the day, or by causing windy conditions around the development. The Council will expect that in the case of a development that has the potential to have an adverse effect on the environmental conditions in a nearby street or public space relevant attenuation measures should be integrated into the proposals.
- 3.22 On-site attenuation measures can also be specified in the planning conditions attached to a planning permission. The Council may require a developer to undertake an assessment (e.g. a wind assessment) of the development as part of the planning application submission. The developer may be required to integrate any findings or recommendations into the finished development. The Council may also require the developer to manage and maintain a development in accordance with an environmental plan, which may need to be approved as part of an application.
- 3.23 In certain cases the adverse effects of a development on the environmental conditions of the public spaces around and within the development may be attenuated by off site measures such as planting trees as a windbreak. Other off-site shading or shielding devices may be required to control or improve the environmental conditions in public and semi public spaces around the proposed development. The Council may require the developer to pay a financial contribution to secure these works.

