Refer to TPS drawings and details for proposed service installation.
Big Foot Fix-it Foot 1000 to be installed as per manufactures instructions. No structural strengthening of existing building is required.




Figure 1 - Existing valley structure within loft space



Figure 2 - Existing steel beam supports within loft space



Figure 3 - Existing Water Tanks within Roof




Existing Beam

Figure 4 - Proposed Condenser Location in existing valley



Figure 5 - Existing steel within loft space and original stud wall from 3rd floor level



Proposed Big Foot Support Detail



25 Bedford Sq. London, WC1A 2NS

THE BEDFORD ESTATES

DRAWING

Proposed Condenser Support

1:100 @ A3, 1:50 @ A1		06/15
DRAWN BY RE	•	си∈ск <u>е</u> д вү
215058	D-301	R≦V