



FLOOR DETAIL 01 New Basement Floor - Buildup


- Make good existing floor by removing any adhesive or defect that could cause the underfloor heating board not to sit perfectly flat -Install Nu heat low pro Max underfloor heating boards and pipes - finish using the self leveing compound supplied with the UFH kit. - Marmoleum sheet floor with tightly butted junctions between sheet edges to give an invisible join, as per the manufacturers recommendations






Existing floor buildup - tiles on adhesive bed - Assumed 18mm plywood - Assumed 200x50 joists





FLOOR DETAIL 02 New Shower floor buildup tiles on adhesive bed with ditramat debonding layer and electric heating mat Wetroom tanking system
18mm WBO ply between joists



No implied license exists. This drawing should not be used to calculate areas for the purposes of valuation. All dimensions to be checked on site by the contractor and such dimensions to be their responsibility. Do not scale drawings. All work must comply with relevant British Standards and Building Regulations requirements. Drawing errors and omissions to be reported to the architect.

info@originstudio.co.uk www.originstudio.co.uk



