




1. THE CONTRACTOR MUST CHECK ALL DIMENSIONS ON SITE BEFORE COMMENCING WORK
2. ALL WORK MUST CONFORM TO CURRENT BUILDING REGULATIONS, BRITISH STANDARDS & CODES OF PRACTICE AND NHBC STANDARDS
3. THESE DRAWINGS ARE TO BE READ IN CONJUNCTION WITH ALL RELEVANT DESIGNER, ENGINEER OR SPECIALIST DRAWINGS AND SPECIFICATIONS
4. ALL DIMENSIONS ARE IN MILLIMETERS UNLESS STATED OTHERWISE
5. THE CONTRACTOR IS RESPONSIBLE FOR PROVIDING ALL NECESSARY TEMPORARY SUPPORT TO THE BUILDING AND ANY ADJACENT STRUCTURES

NOTE:

1. Polyroof 185 System with Associated Trim or similar approved
2. 18mm Polyroof Approved Plywood / OSB3 (TG4) Deck
3. PUR Insulation e.g Kingspan Thermaroof TR26 120mm
4. Vapour Control Layer
5. Treated Timber Batten
6. 12mm Plywood
7. Mechanical Fixing
8. Timber Joist
9. Lead Flashing
10. Plasterboard 12.5mm



DETAIL 4
DORMER CHEEK DETAIL



1. Polyroof 185 membrane
2. Support Batten
3. Drip Trim

NOTES

- a. The drip trim should not sit tight against the fascia.
- b. It may be prudent to incorporate a dpc or similar between the fascia and the drip trim. The dpc should be nailed to the plywood and dressed into the gutter to provide a secondary seal.

DETAIL 5
DORMER DRIP TRAY DETAIL

PROJECT TITLE: LOFT CONVERSION
CLIENT: STEWART BRANNAN
ADDRESS: 18 BELSIZE PARK, LONDON
TITLE:DETAIL
DRAWING NO.: 10
REV:
DRAWN BY: H.D.
Date: JUNE 2017 JUN 2017
SCALE: 1:50 @ A3