

Surface water storage requirements for sites

www.uksuds.com | Storage estimation tool

Calculated by: Alan Clancy

Site name: Belsize Fire Station

Site location: 36 Lancaster Grove, London NW3 \$PB

This is an estimation of the storage volume requirements that are needed to meet normal best practice criteria in line with Environment Agency guidance "Preliminary rainfall runoff management for developments", W5-074/A/TR1/1 rev. E (2012) and the SuDS Manual, C753 (Ciria, 2015). It is not to be used for detailed design of drainage systems. It is recommended that hydraulic modelling software is used to calculate volume requirements and design details before finalising the drainage scheme.

Site coordinates

Latitude: 51.54532° N

Longitude: 0.16632° W

Reference: 6253628

Date: 2018-02-19T11:06:50

Methodology

IH124

Site characteristics

Total site area (ha)	0.1768
Significant public open space (ha)	00.0379
Area positively drained (ha)	0.1389000000
Pervious area contribution (%)	30
Impermeable area (ha)	0.1389
Percentage of drained area that is impermeable (%)	100
Impervious area drained via infiltration (ha)	0
Return period for infiltration system design (year)	100
Impervious area drained to rainwater harvesting systems (ha)	0
Return period for rainwater harvesting system design (year)	10
Compliance factor for rainwater harvesting system design (%)	66
Net site area for storage volume design (ha)	0.14
Net impermeable area for storage volume design (ha)	0.14

^{*} Where rainwater harvesting or infiltration has been used for managing surface water runoff such that the effective impermeable area is less than 50 % of the 'area positively drained', the 'net site area' and the estimates of Qbar and other flow rates will have been reduced accordingly.

Design criteria

Volume control approach	Use long term storage		
		Default	Edited
Climate change allowance factor		1.4	1.4
Urban creep allowance factor		1.1	1.1
Interception rainfall depth (mm)		5	5
Minimum flow rate (I/s)		5	5
Qbar estimation method	Calculate from SPR and SAAR		

SPR estimation method	Calculate from	Calculate from SOIL type	
		Default	Edited
Qbar total site area (I/s)		0.77	
SOIL type		4	4
HOST class		N/A	N/A
SPR		0.47	0.47

Hydrology	Default	Edited
SAAR (mm)	638	638
M5-60 Rainfall Depth (mm)	20	20
'r' Ratio M5-60/M5-2 day	0.4	0.4
Rainfall 100 yrs 6 hrs	63	
Rainfall 100 yrs 12 hrs	102.41	
FEH/FSR conversion factor	1.33	1.33
Hydrological region	6	
Growth curve factor: 1 year	0.85	0.85
Growth curve factor: 10 year	1.62	1.62
Growth curve factor: 30 year	2.3	2.3
Growth curve factor: 100 year	3.19	3.19

Site discharge rates	Default	Edited
Qbar total site area (I/s)	0.77	0.77
Qbar net site area (I/s)	0.6	0.6
1 in 1 year (l/s)	5	5
1 in 30 years (I/s)	5	5
1 in 100 years (I/s)	5	5

Estimated storage volumes	Default	Edited
Interception storage (m³)	6	6
Attenuation storage (m³)	65	65
Long term storage (m³)	0	0
Treatment storage (m³)	17	17
Total storage (excluding treatment) (m ³)	71	71