

The contractor is responsible for checking dimensions, tolerances and references. Any discrepancy to be verified with the Architect before proceeding with the works. Where an item is covered by drawings to different scales the larger scale drawing is to be worked to.

Do not scale drawing. Figured dimensions to be worked to in all cases.

CDM REGULATIONS 2015. All current drawings and specifications for the project must be read in conjunction with the Designer's Hazard and Environment Assessment Record


All intellectual property rights reserved.

GENERAL NOTES

- This drawing is to be read in conjunction with the written specification, if provided and all relevant contract documentation from the design team, with any conflicting information to be brought to the attention of PRP in writing before commencing on site.
- The contractor is to check and verify all levels and dimensions before construction. Any discrepancies are to be brought to the attention of PRP in writing before commencing on site.
- All bases, sub bases and all foundations to Engineers design. Information given here is indicative only.
- Waterproofing of any element to be specified by others, unless specifically noted.
- All proprietary products shall be installed in accordance with manufacturers written instructions.
- Plant numbers are an indication only and plants should be ordered to suit site areas in accordance with scheduled plant densities.
- Any proposed plant substitution shall be agreed with the Landscape Architect prior to ordering.
- Samples of all exterior metal work to be approved by Landscape Architect.
- All drainage inspection chambers to Engineers requirements.
- All dimensions in mm unless otherwise stated.
- Do not scale from this drawing.
- All levels to suit site conditions and to accord with engineer's drawings.
- Lighting to Engineers layout and detail.
- Water points to Engineer's detail.


Notes:

- This drawing is only for indicative purposes only. Final fixing detail, specification and dimensions to be confirmed by engineers.
- This drawing is to be read in conjunction with all relevant contract documentation from the design team, with any conflicting information to be brought to the attention of PRP in writing before commencing on site.
- The contractor is to check and verify all levels and dimensions before construction. Any discrepancies are to be brought to the attention of PRP in writing before commencing on site.
- All dimensions in mm, unless otherwise stated.
- All diagrams provided here are purely indicative.
- All proprietary products shall be installed in accordance with manufacturers written instructions.
- Set climbing plants against walls, fix climbers against wall with wires fixed to vine eyes. Spread out and train stems to optimise coverage and rate of establishment on frame.
- Annual light pruning of growing stems to encourage branching and hasten coverage. Pruning works to be carried out in late winter or early spring.
- Climbing plant numbers, sizes and specifications as indicated on drawing AL4796C - 3201 & 3202. Any proposed plant substitutions to be agreed with the landscape architect prior to ordering.
- Base of climbing plants to be mulched and ensure regular topping up.
- Ensure bed at base of climbers is regularly watered through the growing period to maintain healthy plants.




1 Typical Green Wall Section
1 : 10

Supplier: Jakob Green Wall Stainless Steel Wire Trellis System or similar approved



All images are for illustrative purposes only.



2 Typical Green Wall Elevation
1 : 20

A	28/01/20	Construction Issue	Revised drawing based on client's comments	ZE	BS
-	13/12/19	Preliminary Construction		ZE	BS
Rev	Date	Description		Dwn	Ckd

CHARLIE RATCHFORD

Typical Green Wall Detail

AL4796C-3403

REV A

Construction

Drawn	ZE	Checked	BS	Date	12/11/19	Scale	@ A1 As indicated
-------	----	---------	----	------	----------	-------	-------------------

PRP

prp-co.uk
Surrey
020 8339 3600