



hazard: outline method statement

Structure

Risk Assessment to identify safe removal and replacement of badly decayed joists supporting redundant metal water tank to cloakroom - propping required, replace joist at a time, ensure adequate bearing to masonry. Inspect condition of tank and under-roof during operation.

Waste pipework

Ensure certified full scaffold by specialist installer with correctly positioned lifts to allow safe removal of ironware and PVC pipes. Re-use fixing points where possible, repair all holes/minor damage with Roman cement. Retain all ironware for re-use if joints are clean and corrosion is not significant.

Note: all original / existing fabric retained in-situ unless indicated red for removal

