







30RB UNITS (BP)		140 / 160 KW		30RB UNITS (HP)		140 / 160 KW	
X1	436	X3	453	Y3	506	Y4	1561
Y1	565	Y3	506	Y4	1561	Z3	618
Y2	1620	Y4	1561	Z3	618		
Z1	430						






OPTION FOR 1
OPTION POUR 1

	Ø A
OPTION 264	2" GAZ CONIQUE GAZ 2" CONICAL THREAD
OPTION 266	Ø60.3 mm ep 3.6 mm Ø60.3 mm th 3.6 mm







VOIR DETAIL A
SEE DETAIL



GRILLE EN OPTION
GRILL ON OPTION





TOLERANCE	±10	30RB 140R-160R	DATE	09-11-2020	Feuille Sheet 1/3
					Indice A
			00DCG000393700		

X (mm)	Y (mm)	Z (mm)
734±2	1113±2	507±1



VOIR DETAIL B
SEE DETAIL

ECHELLE 13:320








TROU Ø28
HOLE

DETAIL B
ECHELLE 1:2

GRILLE EN OPTION
GRILL ON OPTION

TOLERANCE	30RB 140R-160R		DATE	Feuille Sheet 2/3 Indice
±10	-		09-11-2020	
		00DCG000393700		A

	ENGLISH	FRANCAIS	DEUTSCHE	ESPANOL	ITALIANO
① →	Unit water inlet and outlet	Entrée et sortie eau unité	Wasser eintritt und austritt	Entrada y salida agua unidade	Entrata e uscita acqua unita
② →	N/A	N/A	N/A	N/A	N/A
③ →	N/A	N/A	N/A	N/A	N/A
④ →	NA	NA	NA	NA	NA
⑤ →	Safety relief valve LP	Soupape de sécurité BP	Verdampfer sicherheitsventil LP	Valvula de seguridad LP	Valvola di sicurezza LP
⑥ →	Safety relief valve HP	Soupape de sécurité HP	Verdampfer sicherheitsventil HP	Valvula de seguridad HP	Valvola di sicurezza HP
⑦ →	NA	NA	NA	NA	NA
⑧ →	NA	NA	NA	NA	NA
⑨ →	NA	NA	NA	NA	NA
⑩ →	NA	NA	NA	NA	NA
⑪ →	NA	NA	NA	NA	NA
⑫ →	NA	NA	NA	NA	NA
⑬ →	Services clearances required	Espace nécessaire à la maintenance	Freiraum für wartung	Espacio necesario para servicio y mantenimiento	Spazio necessario per il servizio
⑭ →	NA	NA	NA	NA	NA
⑮ →	Electrical box	Coffret électrique	Schaltschrank	Caja electrica	Pannello elettrico
⑯ →	Main disconnect switch	Interrupteur général	Haupttrennschalter	Interruptor de desconexión principal	Sezionatore general
⑰ →	N/A	N/A	N/A	N/A	N/A
S	Power supply unit recommend section wire (see IOM)	Raccordement électrique unité section recommandée (voir IOM)	Hauptelektrische anschluss querschnitt (IOM sehen)	Conexiones electricas unidade section recomendada (ver IOM)	Conezione elettrica de l'unità sezione racomandato(vedi IOM)
PT →	Total operating weight standard unit	Poids total en fonctionnement de l'unité standard	Betriebsgewicht standard machine	Peso total en el funcionamiento una el estándar	Peso totale in funzionamento dell'unità standard
	Inlet water	Entrée eau	Wasser eintritt	Entrada agua	Entrata acqua
	Outlet water	Sortie eau	Wasser austritt	Salida agua	Uscita acqua
	Electrical supply entry	Entrée raccordement électrique	Strom Anschlüsse	Entrada cables electricos	Entrata cavi alimentazione
	NA	NA	NA	NA	NA
	Center of gravity	Centre de gravité	Maschinenschwerpunkt	Centro de gravedad	Centro di gravita
M	Handling Rigging of the unit: the sizing of the rigging or lifting elements is the responsibility of the installer	Manutention de l'unité Le dimensionnement des éléments de manutention ou de levage sont sous la responsabilité du manutentionnaire	Anheben des geräts Der installateur ist für die dimensionierung der hebeelemente verantwortlich	Sostienimento de la unidad Las dimensiones de los elementos de sostienimento o levantamiento es responsabilidad de instalador	Sollevamento dell'apparechio La responsabilita del dimensionamento degli elementi di sistema di sollevamento e di pertinenza dell'installatore

TOLERANCE
±10

30RB 140R-160R

DATE
09-11-2020Feuille
Sheet
3/3
Indice

00DCG000393700

A